



Philips  
Headphones with mic

40-mm drivers/closed-back  
Over-ear

**FX5MWT**

## Heavy bass

with lightweight foldable design

Enjoy the best sound experience through premium drivers and adjustable bass boost control. Lightweight and robust, these headphones are crafted for durability and long-wearing comfort.

### **Powerful sound**

- 40-mm neodymium drivers for rich bass and powerful sound
- Noise-isolating around-ear cushions for extended comfort
- Adjustable bass boost control for perfect bass levels

### **Always ready to go**

- Compact foldable design for easy portability and storage
- In-line remote with mic for music and calls on the go

# PHILIPS

Headphones with mic  
40-mm drivers/closed-back Over-ear

# Specifications

## Sound

- Acoustic system: Closed
- Magnet type: Neodymium
- Diaphragm: PET
- Frequency response: 8 - 25,000 Hz
- Impedance: 32 Ohm
- Maximum power input: 40 mW
- Sensitivity: 104 dB
- Speaker diameter: 40 mm
- Type: Dynamic

## Connectivity

- Cable Connection: Two-parallel, symmetric
- Cable length: 1.2 m
- Connector: 3.5 mm stereo
- Finishing of connector: 24k Gold plated
- Type of cable: OFC
- Microphone: Built-in microphone

## Packaging dimensions

- Number of products included: 1

- Packaging type: Carton
- EAN: 69 23410 73211 5
- Packaging dimensions (W x H x D): 19.5 x 22.5 x 5.5 cm
- Gross weight: 0.3355 kg
- Net weight: 0.173 kg
- Tare weight: 0.1625 kg
- Type of shelf placement: Both

## Outer Carton

- Number of consumer packages: 3
- Gross weight: 1.2065 kg
- Outer carton (L x W x H): 21.8 x 19 x 22.5 cm
- Tare weight: 0.6875 kg
- GTIN: 1 69 23410 73211 2
- Net weight: 0.519 kg

## Product dimensions

- Product dimensions (W x H x D): 17.3 x 18.5 x 4 cm
- Weight: 0.168 kg

FX5MWT/00

# Highlights

## 40-mm neodymium drivers

40-mm neodymium drivers deliver heavy bass and powerful sound. The adjustable bass control lets you adapt your sound experience to your individual preference any time you want!

## Adjustable bass boost control

The adjustable bass boost control allows you to get the perfect level of bass for every song. Listen to music the way you like it wherever you go.

## Compact foldable design

A unique folding design allows you to fold the FX headphones into a ball for easier transport and storage.

## In-line remote with mic

The FX5 features a built-in microphone so you can switch from listening to music to taking phone calls in an instant.

## Noise-isolation ear cushions

The over-ear cushions fit around your ears and block out external noise so you can enjoy music on the go.



Issue date 2014-12-05

Version: 1.0.3

12 NC: 8670 001 16992  
EAN: 06 92341 07321 15

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)