



Philips  
docking system for iPod/  
iPhone

App-enhanced  
Aluminium

AJ7035D



## Rise and shine

to great music from your iPod/iPhone

Start your day with this Philips Docking system. It offers Bass Reflex Speaker System for deep powerful bass, 10W RMS output and a dock that takes any iPod/iPhone. Also enjoy enhanced waking and radio experiences via the free Philips App.

### Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Play and charge your iPod/iPhone simultaneously
- FM digital tuning with presets
- 10W RMS total output power

### Start the day your way

- Dual alarm to wake you and your partner at different times
- Gentle wake for a pleasant wake up experience

### Easy to use

- Free HomeStudio app for enhanced wake-up & radio experiences
- Dock any iPod/iPhone, even in its case
- Auto clock synchronization with iPod/iPhone when docked
- MP3 Link for portable music playback
- Time and alarm backup for on-time wakeup even with power cut

# PHILIPS

# Highlights

## Free HomeStudio app



There's no better way to wake up or listen to the radio than with the free Philips HomeStudio app. Simply download the app from the Apple App Store to enjoy a host of exciting features. Advanced alarm set up, for example, gives you greater flexibility in alarm settings - including alarm volume, duration, date and sound. You also get better user interface when you listen to the radio, with easy-to-use station preset functions.

## Play & charge your iPod/iPhone



Enjoy your favorite MP3 music while charging your iPod/iPhone! The dock lets you connect your portable device directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod/iPhone while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The Docking entertainment system automatically

charges your portable device while it is docked.

## FM digital tuning with presets



Digital FM radio offers you additional music options to your music collection on your Philips audio system. Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled

bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## Auto clock synchronization



When connect and dock, this docking system will automatically synchronize the clock with your iPod/iPhone within a few seconds. With this convenient feature, you do not need to set the time manually.

## Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adaptors. What's more, it works even when most protective cases are on - just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.



# Specifications

## iPod compatibility

- Compatible with: iPod touch, iPod touch 2nd generation, iPod touch 2nd gen 8/16/32GB, iPod classic, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod 5th generation, iPod mini

## iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S

## iPod/iPhone App

- App name: HomeStudio
- 5-day weather forecast
- Playback: album/track navigation, playback controls
- Clock: analog display, digital display
- Alarm: multiple alarms, sleep timer
- Radio: FM radio, preset, scan, tune

## Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Antenna: FM fixed pigtail antenna
- Tuner enhancement: auto digital tuning

## Convenience

- Alarms: buzzer alarm, radio alarm, repeat alarm (snooze), dual alarm
- Backlight color: Blue
- Clock: Digital

- Display type: LED display
- Charging device: iPod, iPhone
- Display Enhancements: Brightness Control

## Sound

- Sound system: stereo
- Volume control: rotary (digital)
- Output power: 2 x 5 W

## Loudspeakers

- No. of built-in speakers: 2
- Speaker types: bass reflex speaker system

## Connectivity

- MP3 Link: 3.5mm stereo line in

## Power

- Power supply: 100-240V, 47-63Hz
- Power type: AC Input

## Dimensions

- Product dimensions (WxDxH): 283 x 112 x 118 mm
- Packaging dimensions (WxDxH): 319 x 144 x 180 mm
- Weight incl. Packaging: 1.73 kg
- Weight: 1.36 kg

## Accessories

- Others: User Manual
- Warranty: Warranty Certificate



Issue date 2014-03-14

Version: 2.0.3

12 NC: 8670 000 84819  
EAN: 00 60958 52213 90

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)