



Wireless music

Rechargeable

Just imagine, no hassles with cables and the freedom to move around and enjoy your music with quality FM wireless stereo headphones.

You'll forget you're wearing them!

- 3-way adjustment for a better fit and bass performance
- Lightweight design improves comfort for prolonged use.

The perfect wireless listening experience

- ALC helps prevent audible distortion of input signals
- 32 mm speaker driver delivers high-performance sound

Always ready to go

- FM Wireless transmission for freedom of movement
- Choose from 2 channels to minimise interference
- Reduces costs by using rechargeable batteries

Philips
Wireless hi-fi headphones

FM transmission
Rechargeable

SBCHC8440



PHILIPS

Specifications

Sound

- Acoustic system: closed
- Frequency response: 9–21,000 Hz
- Magnet type: Neodymium
- Sensitivity: 100 dB
- Speaker diameter: 32 mm

Tuner/Reception/Transmission

- Pilot tone frequency: 19
- Effective range: 100 m
- Carrier frequency range: 863.0 - 865.0 MHz
- Channel separation: >30 dB
- Modulation: FM
- Number of channels: 2

Convenience

- Automatic power off
- Battery charging indicator
- Operating time: +/- 15 hours
- Low battery indicator
- Double PLL



Power

- Power supply headphone: 2 x 1.5 V NiMH R03/AAA
- Power supply transmitter: AC/DC adapter 12 V/200 mA

Outer Carton

- EAN: 87 10895 82218 3
- Number of consumer packages: 6
- Gross weight: 5.54 kg
- Outer carton (L x W x H): 45.21 x 33.4 x 33.1 cm
- Net weight: 3.78 kg
- Tare weight: 1.76 kg

Packaging dimensions

- EAN: 87 10895 80707 4
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 10.5 x 21.43 x 28.4 cm
- Gross weight: 0.923 kg
- Net weight: 0.63 kg
- Tare weight: 0.293 kg

Highlights

3-way adjustable ear shells

Enjoy a comfortable fit and experience better bass performance thanks to the three-way adjustable ear shells that fit naturally around your ears.

Lightweight design

The durable, lightweight quality materials of these Philips headphones enhance comfort for extended wear.

Automatic Level Control (ALC)

This smart electronic circuit ensures that the audio input level is automatically adjusted to the right level, preventing distortion and preserving your listening enjoyment.

32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

FM Wireless transmission

With high-frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

2 transmission channels

With a choice of two transmission channels your listening pleasure is protected because you can easily switch to the one with the best reception.

Rechargeable system

The headphone set incorporates facilities for recharging the batteries.

