



wireless portable speaker

- Bluetooth®
- White

BT51W/00

## Make room to dance

Take your tunes out with the Bluetooth speaker that fits in your pocket. This tiny speaker gives you six hours play time and crisp sound, even at maximum volume. The wireless range is 10 m. Plenty of room to dance across the room.

### Benefits

[Tiny speaker.](#) [Crisp sound out loud.](#)

- 1.5" full-range speaker. Crisp, clear sound
- 5 hours play time
- Anti-clipping function. Turn it up without distortion

[Always ready to go](#)

- Really light. Weighs just 90 g
- Really small. 6.1x6.1x7.6 cm

### Features

[Tiny speaker.](#) [Crisp sound.](#)

Weighing just 90 g, you'll barely notice you're carrying this tiny speaker. The 1.5" full-range driver delivers crisp, clear sound even when you turn the volume up.

- Up to 10 m wireless range

[Easy to pair.](#) [Easy to charge.](#)

- Bluetooth is ready to pair with power-on
- USB charging. Micro USB cable included

[5 hrs play time.](#) [USB charging.](#)

The battery gives you 5 hours play time from a full charge. Charging takes less than 3 hours, and is easy via the included micro USB cable.

[Bluetooth connectivity](#)

Pairing with your Bluetooth device is simple. Just power on the speaker and it's ready to pair. The wireless range is 10 m.

# PHILIPS

### Anti-clipping function

Anti-Clipping lets you play music louder and keeps its high quality, even when the battery is low. It accepts a range of input signals, from 300mV to 1000mV and keeps your speakers safe from damage by distortion. This built-in function monitors the musical signal as it goes through the amplifier and keeps peaks

within the amplifier's range, preventing the audio distortion caused by clipping without affecting loudness. A portable speaker's ability to reproduce musical peaks decreases along with battery power, yet anti-clipping reduces peaks caused by low battery, keeping music distortion free.

## Specifications

[field not found 'disclaimer\_text']

### Accessories

Included accessories	Quick install guide World Wide Warranty leaflet
Cable	USB charging cable

### Compatibility

other Bluetooth-enabled device work with	Yes  up to iOS 10.2, Bluetooth 4.2 or below
--	---

### Connectivity

Bluetooth profiles	A2DP AVRCP HFP
Bluetooth range	Line of sight, 10M or 30FT

### Design and finishing

Color	White
-------	-------

### Sound

Output power (RMS)	2W
Sound System	Mono

### Power

Battery type	lithium polymer (built-in)
Operating time on battery	5 hr

### Dimensions

Packaging dimensions (WxDxH)	8.1 x 9.5 x 11.3 cm
Product dimensions (WxDxH)	6.1 x 6.1 x 7.6
Product weight	0.135 kg
Weight incl. Packaging	0.18 kg



data subject to change  
2022, March 1

Version: 7.1.3  
EAN: 6951613995723

© 2022 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)