



Philips  
PhotoFrame

7" LCD

16:9 frame ratio

7FF3FPB



## Share your memories

How many digital pictures are hidden on your PC? See, share, organise and relive your memories with Philips PhotoFrame™, the easiest way to share your memories by displaying your digital photos in stunning quality - without a PC.

### Top quality display for print-like pictures

- ImagEn for sharp and vibrant colour
- Add new glow to old memories with RadiantColor
- SmartContrast: Optimised contrast for visual clarity

### Easily display and manage your digital photos

- Have fun with collages: display multiple photos in one view
- Play slideshows, single photo, thumbnails or show clock
- View photos directly from memory cards - no PC required
- View USB flash drive photos without a PC

### Simple intuitive operation and great convenience

- Intuitive UI, 5-way-keypad for easy navigation and operation

### Green design

- Auto turning display on/off at preset times for power saving

**PHILIPS**  
sense and simplicity

## Specifications

### Picture/Display

- **Viewing angle:** @ C/R > 10, 120° (H) / 100° (V)
- **Lifetime, to 50% brightness:** 20000 hr
- **Brightness:** 200 cd/m<sup>2</sup>
- **Aspect ratio:** 16:9
- **Panel resolution:** 480 x 234
- **Contrast ratio (typical):** 300:1

### Connectivity

- **USB:** USB 2.0 Host, USB 2.0 Slave

### Storage Media

- **USB:** USB flash drive
- **Memory Card Types:** Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro

### Convenience

- **Card Reader:** Built-in (2x)
- **Photo format supported:** JPEG photo, Up to 10MB JPEG files
- **Placement supported:** Photo auto orientation, Landscape, Portrait
- **Buttons and controls:** 3 buttons, 4-way navigation key and enter
- **Playback mode:** Full screen browse, Slideshow, Thumbnail browse
- **Photo edit:** Copy, Delete, Rotate, Zoom & crop
- **Photo effects:** Black and White, Frames, Sepia
- **Slideshow setting:** Random, Sequential, Transition effect
- **Screen background:** Black, White, Gray, Ambient colour, Auto-fit
- **Setup function:** Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Alarm
- **System status:** Firmware version, Remaining memory
- **Connected media status:** Connected media, Remaining memory

- **Plug & Play Compatibility:** Windows Vista, Windows 2000/XP or later, Mac OS X
- **Regulatory Approvals:** BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- **On-Screen Display languages:** English, Spanish, German, French, Italian, Dutch, Danish, Russian, Simplified Chinese, Japanese

### Accessories

- **Included Accessories:** AC-DC Adapter, USB cable, Stand, Quick start guide, User Manual

### Dimensions

- **Set dimensions with stand (W x H x D):** 206.4 x 139.3 x 103 mm
- **Weight:** 0.345 kg
- **Temperature range (operation):** 0°C to 40°C
- **Temperature range (storage):** -20°C to 70°C

### Power

- **Power consumption:** 5 W
- **Power mode supported:** AC powered

### Packaging dimensions

- **Packaging dimensions (W x H x D):** 26.1 x 22.2 x 7.8 cm
- **Nett weight:** 0.721 kg
- **Gross weight:** 0.841 kg
- **Tare weight:** 0.12 kg
- **EAN:** 87 12581 41216 6
- **Number of products included:** 1
- **Packaging type:** Carton

### Outer Carton

- **Outer carton (L x W x H):** 51.4 x 28.2 x 25.5 cm
- **Nett weight:** 4.326 kg
- **Gross weight:** 6.046 kg
- **Tare weight:** 1.72 kg
- **GTIN:** 1 87 12581 41216 3
- **Number of consumer packagings:** 6

## Product highlights

### ImagEn technology

*ImagEn is exclusive Philips photo enhancement technology that automatically analyses your photos to correct colour and adjust for optimal contrast: ImagEn separates colours to avoid "crosstalk" adjusts brightness distribution for great visual contrast and corrects Gamma for colour accuracy.*

### RadiantColor

*RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.*

### SmartContrast

*SmartContrast is Philips technology that analyses the contents you are displaying, automatically adjusting colours and controlling backlight intensity to dynamically enhance contrast for the best digital images and optimum contrast for more entertainment fun when viewing videos or playing games where dark hues are displayed; when you select the Economy mode, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.*

### Multiple-photo collage effect

*It's a slideshow effect to show photos in collage form that automatically and randomly compiles different photos together to avoid unattractive borders that may result from photos which are smaller than screen size.*

### Multiple viewing modes

*Flexible display modes give you the freedom to display your photos one image at a time, in thumbnail mode for quick, easy searches, or to create a slideshow of your most treasured photos.*

### Viewing photos in USB flash

*A USB connector for easy viewing and sharing of photos stored on USB flash drive.*

### SmartPower

*A timer turns PhotoFrame on and off at the hours you select, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs. Three programmable weekday timeslots along with one weekend timeslot give you flexibility to fit your personal schedule.*



Issue date 2009-01-22

Version: 3.0.8

12 NC: 8670 000 38991  
EAN: 87 12581 41216 6

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)