



Philips
PhotoFrame

14.2 cm (5.6") LCD

4:3 frame ratio

6FF3FPW



Share your memories

How many digital pictures are hidden on your PC? See, share, organize and relive your memories with Philips PhotoFrame™, the easiest way to share your memories by displaying your digital photos in stunning quality - without a PC.

Top quality display for print-like pictures

- Images for sharp and vibrant color
- 4:3 aspect ratio for optimal distortion-free display
- Add new glow to old memories with RadiantColor

Easily display and manage your digital photos

- Have fun with collages: display multiple photos in one view
- View USB flash drive photos without a PC

Simple intuitive operation and great convenience

- Intuitive UI, 5-way-keypad for easy navigation and operation
- Auto photo orientation to fit portrait or landscape modes

Green design

- Auto on/off display at pre-set times for power saving

Stylish and curve design complements your photos

- Tasteful glossy finishing and great touch feeling

PHILIPS
sense and simplicity

Highlights

imagen technology

imagen is exclusive Philips photo enhancement technology that automatically analyzes your photos to correct color and adjust for optimal contrast: imagen separates colors to avoid "crosstalk" adjusts brightness distribution for great visual contrast and corrects Gamma for color accuracy.

4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo to be displayed in 4:3 ratio for the best viewing experience.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Multiple-photo collage effect

It's a slideshow effect to show photos in collage form that automatically and randomly compiles different photos together to avoid unattractive borders that may result from photos which are smaller than the screen size.

Viewing photos in USB flash

A USB connector for easy viewing and sharing of photos stored on USB flash drive.

Auto on/off display

A timer turns PhotoFrame on and off at the hours you select, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognizes PhotoFrame orientation and displays each photo in its proper mode.



Specifications

Outer Carton

- GTIN: 1 06 09585 15370 4
- Number of consumer packagings: 6
- Gross weight: 4.9 kg
- Outer carton (L x W x H): 50.5 x 23.9 x 24.5 cm
- Nett weight: 3.192 kg
- Tare weight: 1.708 kg

Packaging dimensions

- UPC: 6 09585 15370 7
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 22.48 x 21.82 x 8.1 cm
- Gross weight: 0.713 kg
- Nett weight: 0.532 kg
- Tare weight: 0.181 kg

Accessories

- Included accessories: AC-DC Adapter, Quick start guide, Stand, User Manual

Connectivity

- USB: USB 2.0 Host

Convenience

- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Card Reader: Built-in (1x)
- Connected media status: Connected media, Remaining memory
- On-Screen Display languages: Danish, Dutch, English, French, German, Italian, Japanese, Russian, Simplified Chinese, Spanish
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Photo effects: Black and White, Frames, Radiant color, Sepia
- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Placement: Landscape, Photo auto orientation,

Portrait

- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Plug & Play Compatibility: Mac OS X, Windows 2000/XP or later, Windows Vista
- Regulatory approvals: BSMI, CCC, CE, C-Tick, FCC, GOST, PSB, Switzerland, UL/cUL
- Screen background: Auto-fit, Black, Gray, White
- Setup function: Alarm, Auto on/off, Beep on/off, Brightness adjustment, Clock display enable/disable, Language, Set time and date, Status
- Slideshow setting: Random, Sequential, Transition effect
- System status: Firmware version, Remaining memory

Dimensions

- Set dimensions with stand (W x H x D): 167.8 x 135.3 x 100.73 mm
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

Picture/Display

- Aspect ratio: 4:3
- Brightness: 200 cd/m²
- Contrast ratio (typical): 300:1
- Lifetime, to 50% brightness: 20000 hr
- Panel resolution: 320 x 234
- Viewing angle: @ C/R > 10, 130° (H) / 110° (V)

Power

- Power consumption: 3 W
- Power mode supported: AC powered

Storage Media

- USB: USB flash drive
- Memory Card Types: Memory Stick, Memory Stick Pro, Multimedia Card, Secure Digital (SD), Secure Digital (SDHC), xD card



Issue date 2013-02-09

Version: 5.0.12

12 NC: 8670 000 39113
UPC: 6 09585 15370 7

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com