

PHILIPS



Bluetooth® sports
headphones

Best for outdoor use

Bluetooth®

Sweat/waterproof

Ear bud



SHQ6500BL

PUSH YOUR LIMITS, wirelessly

Wireless sports earbud headsets

Philips Actionfit RunFree wireless sports headphones bring new levels of freedom and energy to your workouts. With a secure fit, tough waterproof design and powerful bass, they're built to keep your body moving.

Protection

- Ideal for any workout with IPX2 sweat resistance
- Kevlar® reinforced cable for ultimate durability

Freedom

- Anti-slip rubber ear caps keep the headphone in — always.
- Bluetooth wireless connection for tangle-free workouts
- Control your music and pick up calls while training

Intensity

- Open acoustics let sound in for better awareness and safety
- High performance sound pushes you further

Specifications

Sound

Acoustic system: Semi-closed, Closed
Sound Enhancement: Echo Control, Noise Reduction
Speaker diameter: 13.6 mm
Diaphragm: PET
Impedance: 32 Ohm
Magnet type: Neodymium
Voice coil: Copper
Frequency response: 15–22,000 Hz
Maximum power input: 10 mW
Sensitivity: 107 dB
Type: dynamic

Connectivity

Bluetooth version: 4.1
Bluetooth profiles: A2DP, AVRCP, HFP, HSP
Maximum range: Up to 10 m

Outer Carton

Length: 19 cm
Number of consumer packages: 3
Width: 11 cm
Gross weight: 0.278 kg
Height: 13.3 cm
GTIN: 1 69 25970 71012 8
Net weight: 0.09 kg
Tare weight: 0.188 kg

Convenience

Call Management: Answer/End Call, Switch between call and music, Call on Hold
Volume control

Power

Rechargeable
Battery Type: Li-Polymer
Music play time: 4.5* hour(s)
Standby time: 55* hr
Talk time: 4.5* hr
Battery weight: 2.5g

Packaging dimensions

Height: 17.5 cm
Packaging type: Carton
Type of shelf placement: Both
Width: 9.5 cm
Depth: 3 cm
Number of products included: 1
EAN: 69 25970 71012 1
Gross weight: 0.066 kg
Net weight: 0.03 kg
Tare weight: 0.036 kg

Product dimensions

Height: 2 cm
Width: 10 cm
Depth: 4 cm
Weight: 0.014 kg

Accessories

Quick start guide: Quick start guide
USB cable: Included for charging
Ear fit stabiliser: 2 pairs

Design

Colour: Carbon lime & black

Highlights

Ambient sound awareness

Enjoy quality sound that doesn't block out the world around you. The open acoustic design lets ambient sound in, so you can stay aware of your surroundings and stay safer exercising in the outdoors.

Anti-slip rubber ear caps

C-shaped rubberised ear tips keep the ActionFit earphones tightly in your ears so you can focus on your workout, not on keeping them in.

Bluetooth 4.1

Bluetooth technology provides hassle-free wireless music.

Extra durable Kevlar® cable

Your ActionFit headphones are designed for durability and strength. Its Kevlar-coated cable is well protected against tearing and breaking, and can withstand extreme environments — and workouts.

High-performance sound

13.6-mm (0.5") drivers pump out high performance sound, pushing you to perform at your best.

Sweat proof

Don't be afraid to break a sweat. With an IPX2 rating, you can get sweaty and work out in the rain without any moisture entering the earpiece.

Mic and control

Stay connected. The built-in microphone and track controls allow you to change music or pick up calls quickly and easily while you train.

