

Philips Docking speaker with Bluetooth

for Android



AS111



Free your music and charge your Android phone

Obsessed with sound

Get great sound as this speaker plays and charges your Android powered phone, and auto-synchronises its clock with your device. Songbird comes packaged so you can sync music between your phone and PC, and a free app for even more functions.

Surprisingly rich sound

- Bluetooth music streaming from Android powered device
- · Rich omni-directional sound to fill your bedroom
- Neodymium speakers for pure balanced sound
- \bullet Shielding technology to block mobile phone interference

Elegant and compact

- Elegant and compact design to fit on any bed table
- 360-degree design for gorgeous look from any angle

Designed for your bedroom

- Auto clock synchronisation with Android powered phone
- Soft glow night light

Easy to use

- Discover, share music and more features via DockStudio app
- Songbird to discover, play and sync music between your PC and Android
- Smartly designed FlexiDock to fit/charge Android phone





Highlights

FlexiDock



The Philips FlexiDock is perfect for Android powered phones. Its unique design cleverly docks most Android powered phones - whether the phone's connection socket is at the bottom, on the side or even on the top. This extreme flexibility is the first of its kind, catering to Android powered phones that are made by different manufacturers with no standardised position and orientation for the micro USB connection socket. The dock is also adjustable to hold the phone in both portrait and landscape positions, letting you position your Android powered phone at the centre of the speaker

DockStudio app for Android



The free Philips DockStudio app brings a myriad of unique features to your docking speakers. You can listen to thousands of Internet radio stations worldwide, browse your music collection and share what you are listening to with friends via Facebook, or photos of the artist on Flickr. The app comes with Songbird music function, so you can discover, play and sync media seamlessly between PC and Android powered devices. In Clock mode, the app lets you set multiple customised music alarms and gives updated weather reports. Completely free, the app can be downloaded from Google play.





Bluetooth music streaming



Listen to all your favourite songs on a speaker that delivers fabulous sound. This docking speaker plays music from your Android powered devices via Bluetooth. Simply download the free Philips DockStudio app and the Bluetooth will automatically be turned on and connect once when your device is docked. You get to enjoy powerful and outstanding sound, with unbeatable convenience. Hardly anything else sounds as good.

Songbird music network



Songbird is a simple, easy-to-use PC program and Android app. It lets you discover and play all your media and sync it seamlessly with your PC. Its intuitive and powerful music management features let you discover new artists and music styles directly in the program through music and media shops, services and websites. Play your own library and media from the Internet and seamlessly sync all of it from your PC to your Android devices.

Auto clock synchronisation

Simply connect your Android powered phone, and the docking speaker will automatically synchronise its clock's time with your phone's.

Specifications

Android device compatibility

- Android version 2.1 or above
- Bluetooth version 2.1 or above
- Micro USB
- Check out: www.philips.com/FlexiDock for more details and the latest compatibility information

DockStudio App for Android

- App name: DockStudio, Free download from Android Market
- · Compatibility: Philips docking speaker for Android
- Music playback: Songbird Android App
- Bluetooth connection: between Android phone and docking speaker. Fully automatic connection when docked
- Internet radio: TuneIn with over 7000 stations
- Clock: Analogue display, Digital display
- Alarm: Multiple alarms, Sleep timer, Wake up to music, Wake up to nature sounds, Wake up to photos

Sound

- Output power (RMS): 4 W
- Sound System: Stereo
- Volume Control: Volume Control up/down

Audio Playback

 Cradle playback mode: Play and Pause, Next and Previous track, Charging Android phone

Loudspeakers

· Neodymium magnet system

Convenience

· Clock/Version: Digital

Connectivity

- Bluetooth version: 2.1
- Bluetooth profiles: A2DP, AVRCP, SPP
- \bullet Bluetooth range: line of sight, 10 m or 30 ft

Dimensions

- Product dimensions (WxDxH): 171 x 67 x 171 mm
- Weight: 0.75 kg
- Weight incl. Packaging: 1.03 kg

Powe

Power supply: 100-240 VAC, 50/60 Hz



Issue date 2017-04-05

Version: 7.0.4

12 NC: 8670 000 81633 EAN: 87 12581 61966 4 © 2017 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com