

Philips
Digital AV receiver system

HTR5204



Amplify and simplify your home entertainment

Thinking of transforming your DVD player or recorder into a complete home entertainment system? Just match it with this stylish digital receiver system to get a theatre-like audio/video experience and accurate music reproduction.

Brings audio to life

- Advanced Class D Amplifier for compact, powerful sound
- DTS, Dolby Digital and Pro Logic II surround sound
- 5.1 channel audio input for better sound from other devices

Connect and enjoy multiple sources

- MP3 Line-in for music playback from Portable Media Players
- Built-in FM/MW tuner

Easy to set up and use

- Quick and easy setup for no-fuss installation
- Easy-fit™ connectors with colour-coding for a simple setup

PHILIPS
sense and simplicity

Specifications

Sound

- **Total Output Power:** 600 W
- **Output power (RMS):** 6 x 115 W
- **D/A converter:** 24-bit, 192 kHz
- **Frequency response:** 150 - 18000 Hz
- **Signal to noise ratio:** >60 dB
- **Sound System:** Dolby Digital, Dolby Prologic II, DTS, Stereo
- **Sound Enhancement:** Treble and Bass Control, Class "D" Digital Amplifier, Night Mode
- **Equalizer settings:** Concert, Drama, Action, Classic, Jazz, Rock, Digital, Sci-Fi

Tuner/Reception/Transmission

- **Tuner Bands:** MW, FM
- **RDS:** Station Name
- **No. of pre-set Audio Channels:** 40

Connectivity

- **Front/Side connections:** Headphone out, MP3 Line-in
- **Rear Connections:** AM/MW Antenna, AUX in, Digital coaxial in, Digital optical in, Easy-Fit speaker connectors, FM Antenna, TV in (audio, cinch)

Electricity

- **Power supply:** 220-240 V, 50 Hz
- **Power consumption:** 100 W
- **Standby power consumption:** < 1 W

Loudspeakers

- **Satellite speaker freq range:** 150-20,000 Hz
- **Satellite speaker impedance:** 4 ohm

- **Satellite speaker drivers:** 3" full-range woofer
- **Centre Speaker:** 3-way, Magnetically shielded
- **Centre speaker drivers:** 1 x 2" tweeter, 2 x 2.5" woofers
- **Centre speaker impedance:** 8 ohm
- **Centre freq range:** 150-20,000 Hz
- **Subwoofer type:** Passive
- **Subwoofer driver:** 6.5" high-efficiency woofer
- **Subwoofer impedance:** 8 ohm
- **Subwoofer freq range:** 40-150 Hz

Accessories

- **Included Accessories:** Audio Cable, Coax digital audio cable, User Manual, 2 x AAA Batteries, AM antenna, FM antenna, Power cord, Quick start guide, Remote Control, World Wide Warranty leaflet

Dimensions

- **Set dimensions (W x H x D):** 435 x 55 x 324 mm
- **Set weight:** 2.8 kg
- **Surround Speaker dimensions (W x H x D):** 95.5 x 198 x 75 mm
- **Surround Speaker Weight:** 0.62 kg
- **Center speaker dimensions (W x H x D):** 435 x 93.5 x 67 mm
- **Centre Speaker Weight:** 1.28 kg
- **Subwoofer dimensions (W x H x D):** 159.5 x 355.5 x 370 mm
- **Subwoofer Weight:** 4.78 kg
- **Packaging dimensions (W x H x D):** 550 x 496 x 310 mm
- **Weight incl. Packaging:** 11.8 kg

Product highlights

MP3 line-in

MP3 Line-in uses Plug and Play technology that allows direct playback of MP3 content via the home theatre system by simply plugging your portable MP3 player into the built-in headphone jack. Now you can enjoy the superb sound quality of the Philips Home Theatre System while playing your favourite music from your portable MP3 player.

Advanced Class D Amplifier

DTS, Dolby Digital, ProLogic II

A built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

5.1 channel audio input

Built-in FM/MW tuner

Quick and easy setup

Easy-fit™ connectors

Colour-coded connectors provide a simple and user-friendly solution for connecting the speakers and subwoofer to the centre unit of the home entertainment system simply by plugging the connectors into the matching coloured interface at the rear of the centre unit.



Issue date 2009-01-22

Version: 1.2.11

12 NC: 8670 000 26273
EAN: 87 12581 30775 2

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com