

Philips Portable Speaker System

SBA230





Pure sound quality 2 x 2W

Powerful XSI Acoustics

Take this portable speaker system with you anywhere you go to share high quality powerful sound with your friend from any portable device. The speakers fit easily into your pocket or bag, and are protected by a handy pouch.

Powerful Sound

- Built-in speakers featuring XSL Acoustics for dynamic sound
- Dynamic Bass Boost electronically enhances the low tones

Take your music with you

- Small and lightweight for carrying in your pocket or bag
- · Carrying pouch to protect your speakers when not in use
- Universal use with all portable entertainment equipment

Always ready to go

• Cable neatly stored when not in use



Specifications

Sound

- Frequency response: 100 20 000 Hz
- · Impedance: 4 ohm
- RMS Power rating: 2x2W (4W)
- Sensitivity: 80 dB
- Sound Enhancement: Dynamic Bass Boost
- Speaker diameter: 40 mm
- Type: Neodymium

Connectivity

- Cable length: 0.4 m
- Connector: 3.5 mm stereo
- · Finishing of connector: Nickel plated

Convenience

- · Bass level control
- Operating time: 6 hours
- Power on indication
- Volume control

Accessories

• Pouch

Power

- Adaptor type: 9V 500mA
- Battery type: AAA, LR03
- Battery voltage: 1.5 V
- Number of batteries: 6

Packaging dimensions

- Packaging dimensions (W \times H \times D): 7.2 \times 8.6 \times 2.4 inch
- Gross weight: 0.906 lb
- Nett weight: 0.608 lb
- Tare weight: 0.298 lb
- · Number of products included: 1
- Packaging type: Carton
- UPC: 6 09585 14916 8

Outer Carton

- Gross weight: 6.900 lb
- Outer carton (L x W x H): 16.1 x 8.0 x 9.0 inch
- Nett weight: 3.651 lb
- Tare weight: 3.250 lb
- GTIN: 2 06 09585 14916 2
- · Number of consumer packagings: 6

Inner Carton

- Gross weight: 2.046 lb
- Inner carton (L \times W \times H): 7.5 \times 5.1 \times 8.0 inch
- Nett weight: 1.217 lb
- · Tare weight: 0.829 lb
- GTIN: 1 06 09585 14916 5
- Number of consumer packagings: 2

Highlights

XSL Acoustics

Enjoy dynamic sound and powerful bass performance from your ShoqBox with XSL Acoustics. Impressive sound is produced by combining bright, brisk treble and mid range sound with elastic, powerful bass. Innovative use of hightech materials like titanium cone and neodymium magnet deliver sound output that's nearly double the power of a traditional speaker driver of the same size. Precise tuning between the speaker driver, the small acoustic architecture and the circuitry ensures superbly dynamic sound and optimizes bass performance from the smallest sound enclosure.

DBB Dynamic Bass Boost

Activate the Dynamic Bass Boost (DBB), and the low-end bass frequencies are electronically enhanced to achieve consistent sound reproduction, especially when the speaker volume is set at a low level. You hear impressive bass at all times.

Compact and lightweight

Small and lightweight you'll hardly notice it's with you. Pop it in your pocket or bag and take it anywhere.

Carrying pouch

Look after your speaker and stop the cable getting tangled by storing it in this handy soft pouch when not in use.

For portable equipment

Universal use with all portable entertainment equipment. Simply connect using the 3.5mm plug.

Speaker cable management

With it's unique design, cable storage is no longer an issues. Simply pack and go.



Issue date 2013-01-31

Version: 2.0.3

2013-01-31

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 37259 UPC: 6 09585 14916 8

www.philips.com