

Philips
Micro Hi-Fi System



DCM276



Enjoy iPod music in superb sound

Playback your iPod music in superb sound while recharging it with the Philips Micro system DCM276. The flat, compact design is also wall-mountable to complement any interior. USB direct for added playback options.

Enjoy your music from multiple sources

- Play and charge your iPod
- Play CD, CD-R and CD-RW
- Enjoy MP3/WMA music directly from your portable USB devices
- FM digital tuning with presets

Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2 x 5 W RMS total output power

Design that blends into your interior(s)

- Front motorised CD door with viewing window
- Stylishly sleek and compact design
- Stylish slim design with table-stand and wall-mount options

PHILIPS

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a

button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play and charge your iPod

Enjoy your favourite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favourite music in superb quality. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment

system automatically charges your iPod while it is docked.

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.



Specifications

Sound

- Output power (RMS): 2 x 5 W
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Volume Control: Volume Control up/down

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 4" woofer
- Built-in speakers: 2

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD, USB flash drive
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 20-Track Programmable, Fast Forward/Reverse, Next/Previous Track Search
- Loader Type: Motorised, Front
- ID3-tag support
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop
- Cradle playback mode: Charging iPod, Fast forward and reverse, Next and Previous track, Play and Pause

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto Store
- RDS: Programme Type, Station Name, RDS Clock Set
- Station presets: 20

Connectivity

- Headphones: 3.5 mm
- Other connections: FM Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm, iPod Alarm
- Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt

Accessories

- Included accessories: Guarantee booklet
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- Remote control: 31-key remote
- User Manual: 16 languages

Dimensions

- Main speaker dimensions (W x H x D): 0 x 0 x 0 mm
- Set dimensions (W x H x D): 542 x 238 x 102 mm
- Packaging dimensions (W x H x D): 614 x 310 x 159 mm

Power

- Power supply: 220-240 V, 50 Hz

iPod compatibility

- Compatible with: iPod, iPod 5th Generation, iPod classic, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod touch, iPod touch 2nd Generation, iPod with colour display



Issue date 2013-05-10

Version: 1.0.5

12 NC: 8670 000 55606
EAN: 87 12581 50005 4

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com