

Philips
DVD home theater system



HTS3011



Simply sounds great

with compact speakers

Relax and immerse yourself in movies in your very own living room. Enjoy high quality multi-channel surround sound from practically any type of disc.

Bring audio and video to life

- Dolby Digital and Pro Logic II surround sound
- Advanced Class D Amplifier for compact, powerful sound
- 12-bit/108MHz video processing for sharp and natural images

Easy to set up

- RGB on Scart single connection for high-quality video
- Easy-fit™ connectors with color-coding for a simple set-up

Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Built-in FM tuner
- Plays DivX, MP3, WMA and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

PHILIPS

Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz

Sound

- Total Power (RMS): 200 W
- Output power (RMS): 4 x 25W + 2 x 50W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 180 - 18000 Hz
- Signal to noise ratio: >60 dB
- Sound System: Dolby Digital, Dolby Prologic II, Stereo
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode
- Equalizer settings: Action, Classic, Concert, Drama, Gaming, Lounge, Rock, Sports

Video Playback

- Playback Media: CD-R/CD-RW, DVD+R/+RW, DVD-R/-RW, DVD-Video, Video CD/SVCD
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, MPEG4
- Video disc playback system: PAL, NTSC

Audio Playback

- Playback Media: CD-R/RW, DVD+R/+RW, DVD-R/-RW, CD
- Compression format: MP3, WMA
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Playback Media: DVD+R/+RW, CD-R/RW, DVD-R/-RW
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

Tuner/Reception/Transmission

- Tuner Bands: FM
- No. of preset Audio Channels: 40

Connectivity

- Rear Connections: Composite video (CVBS) output, FM Antenna, AUX in, Easy-Fit Speaker Connectors, Scart

Power

- Power supply: 50Hz, 220-240V
- Standby power consumption: < 1 W
- Power consumption: 40 W

Loudspeakers

- Satellite speaker drivers: 3" full range woofer
- Satellite speaker impedance: 4 ohm
- Satellite speaker freq range: 150-20000 Hz

- Center Speaker: Magnetically shielded
- Center speaker drivers: 3" full range woofer
- Center speaker impedance: 8 ohm
- Center freq range: 150-20000 Hz
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer type: Passive
- Subwoofer impedance: 8 ohm
- Subwoofer freq range: 45 - 150 Hz

Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, CVBS video cable, FM antenna, User Manual, Quick start guide, World Wide Warranty leaflet

Dimensions

- Set dimensions (W x H x D): 360 x 55 x 332 mm
- Set weight: 2.58 kg
- Surround Speaker dimensions (W x H x D): 100 x 95.5 x 83.5 mm
- Surround speaker Weight: 0.47 kg
- Center speaker dimensions (W x H x D): 100 x 95.5 x 83.5 mm
- Center Speaker Weight: 0.52 kg
- Subwoofer dimensions (W x H x D): 131 x 315.5 x 386 mm
- Subwoofer Weight: 3.6 kg
- Packaging dimensions (W x H x D): 446 x 417 x 378 mm
- Weight incl. Packaging: 11.3 kg

Outer Carton

- Gross weight: 10.62 kg
- Outer carton (L x W x H): 56.2 x 39.4 x 30.7 cm
- Nett weight: 8.822 kg
- Tare weight: 1.798 kg
- EAN: 87 12581 38894 2
- Number of consumer packagings: 1

Packaging dimensions

- Packaging dimensions (W x H x D): 56.2 x 30.7 x 39.4 cm
- Gross weight: 10.62 kg
- Nett weight: 8.822 kg
- Tare weight: 1.798 kg
- EAN: 87 12581 38894 2
- Number of products included: 1
- Packaging type: Carton

Product dimensions

- Cable length: 0 cm
- Product dimensions (W x H x D): 0 x 0 x 0 cm
- Weight: 0 kg

Highlights

DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

Dolby Digital and Pro Logic II

A built-in Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

Advanced Class D Amplifier

Advanced Class D Amplifier for compact, powerful sound

12-bit/108MHz video processing

12-bit Video DAC is a superior Digital-to-Analogue Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother gradation of colors, resulting in a more vibrant and natural picture. The limitation of the usual 10bit DAC become in particular apparent while using large screens and projectors.

RGB on Scart connectivity

RGB on Scart is a cable connection that provides easy connectivity for high quality video output.

Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.

Easy-fit™ connectors

Color-coded connectors provide a simple and user-friendly solution to connect the speakers and subwoofer to the center unit of the home entertainment system simply by plugging the connectors in the matching colored interface at the rear of the center unit.



Issue date 2017-04-04

Version: 4.0.8

12 NC: 8670 000 36272
EAN: 87 12581 38894 2

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com