



Wireless HiFi Headphone

- Over-ear

SHC5100/10

## Wireless freedom

Fully rechargeable wireless headphones

No more hassles with the cables, you can feel free to move around at home for music enjoyment. With the rechargeable and lightweight design of these Philips SHC5100/10 headphones, you don't need to bother for long wearing time.

### Benefits

#### The perfect wireless listening experience

- 32mm speaker driver delivers high performance sound
- FM Wireless transmission for freedom of movement

#### Comfortable for long use

- Self-adjusting inner headband
- Lightweight design improves comfort for prolonged use.

#### Convenience

- Fully rechargeable
- Choose from 2 channels to minimize interference

### Features

#### 32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

**PHILIPS**

### Self-adjusting inner headband

Typically headphones worn outdoors are adjustable by sliding an extendable headband into position. This can be cumbersome as it usually has to be done every time you use it. Get your music fix faster and easier with these headphones' flexible, self-adjusting inner headband. It will automatically adjust to your head's shape and size.

### Lightweight design

The durable, lightweight quality materials of these Philips headphones enhance comfort for extended wearing.

## Specifications

[field not found 'disclaimer\_text']

### Sound

Acoustic system	Closed
Frequency response	20 - 20 000 Hz
Magnet type	Neodymium
Sensitivity	100 dB
Speaker diameter	32 mm
Impedance	24 ohm

### Tuner/Reception/Transmission

Channel separation	> 30 dB
Pilot tone frequency	19 kHz
Effective range	100 m
Carrier frequency range	863.0 - 865.0 MHz
Modulation	FM
Number of channels	2

### Convenience

Battery charging indication	Yes
Double PLL	Yes
Operating time	~10 hours
Automatic power off	Yes

### Power

Power supply headphone	2 x 1.5 V NiMH R03/AAA
Power supply transmitter	AC/DC adapter 8V/200mA

### Outer Carton

Gross weight	2.86 kg
--------------	---------

### FM Wireless transmission

With high frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

### Fully rechargeable

The headphones are designed to be used with rechargeable batteries. No worry on cost for repeated use.

### 2 transmission channels

With a choice of two transmission channels your listening pleasure is protected because you can easily switch to the one with the best reception.

Nett weight	1.254 kg
Tare weight	1.606 kg
Number of consumer packagings	3
Height	32.5 cm
Length	32.5 cm
Width	26 cm
GTIN	1 69 23410 70493 5

### Packaging dimensions

Depth	10 cm
Gross weight	0.752 kg
Height	32 cm
Nett weight	0.418 kg
Tare weight	0.334 kg
Width	24 cm
Number of products included	1
Packaging type	Display
EAN	69 23410 70493 8
Type of shelf placement	Both

### Product dimensions

Depth	8.5 cm
Height	22 cm
Weight	0.178 kg
Width	19.5 cm



data subject to change  
2018, January 1

Version: 9.3.8  
EAN: 6923410704938

© 2018 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)