



Philips  
True Wireless  
Headphones

#### Earbuds with in-ear fit

Portable charging case  
IPX5 water protection  
Up to 26 hours play time



TAT3216BK

## Secure and comfortable. Touch controls.

From phone meeting to playlists in the park—these true wireless headphones are there for you. They don't mind rain or sweat, and you get great sound and a secure in-ear fit that won't come loose. Plus 24 hours play time with the case.

#### Portable charging case. Up to 24 hours play time

- IPX5 water and sweat resistant
- Portable USB-C charging case. 18 hours extra play time
- 6 hours play time. Charge 15 minutes for an extra hour
- Clear sound, punchy bass. 6 mm neodymium drivers

#### Extremely convenient. Super comfortable.

- Secure, comfortable in-ear fit
- 2 colors. Soft wing tips. 3 sizes of ear-tip cover
- Make calls using a single earbud. Mono mode

#### From favorite playlist to catch-up call

- Touch controls. Built-in mic. Easy pairing
- Quick reconnect to your phone when you open the case
- Easily wake your phone's voice assistant
- Custom sound control. Philips Headphones app

# PHILIPS

## True Wireless Headphones

Earbuds with in-ear fit Portable charging case, IPX5 water protection, Up to 26 hours play time

# Specifications

### Sound

- Impedance: 16 Ohm
- Speaker diameter: 6 mm
- Sensitivity: 105 dB (1K Hz)
- Frequency range: 20 - 20,000 Hz
- Maximum power input: 3 mW
- Driver type: Dynamic

### Telecommunication

- Microphone for call: 1 mic

### Connectivity

- Bluetooth version: 5.0
- Supported codec: SBC
- Maximum range: Up to 10 m
- Bluetooth profiles: A2DP, AVRCP, HFP
- Type of wireless transmission: Bluetooth
- Wireless
- Microphone: Built-in microphone

### Convenience

- Philips Headphones app support
- Firmware updates possible
- Water resistance: IPX5
- Mono mode for TWS
- Type of controls: Touch
- Automatic power off

### Design

- Color: Black
- Wearing style: In-ear
- Ear coupling material: Silicone
- Ear fitting: In-ear
- In-ear fitting type: Silicone ear tip

### Power

- Music play time: 6 + 18 hr
- Talk time: 5 hr
- Battery type(Earbud): Lithium-ion (built-in)
- Battery capacity(Earbud): 50 mAh
- Battery type(Charging case): Lithium-ion (built-in)
- Battery capacity(Case): 450 mAh
- Battery life standby time: 80 hr
- Charging time: 2 hr
- Fast charging time: 15 mins for 1 hr
- Number of batteries: 3 pcs
- Battery weight (Total): 13 g
- Rechargeable

### Voice assistant

- Voice assistant support
- Voice assistant activation: Manual
- Voice assistant compatible: Apple Siri, Google Assistant

### Accessories

- Eartips: 3 pairs (S/M/L)
- Charging case
- Charging cable: USB-C cable, 500 mm
- Quick Start Guide

### Outer Carton

- Number of consumer packagings: 24
- Outer carton (L x W x H): 31 x 22 x 34.5 cm
- Gross weight: 4.88 kg
- Nett weight: 1.992 kg
- Tare weight: 2.888 kg
- GTIN: 1 48 95229 11748 5

### Inner Carton

- Number of consumer packagings: 3
- Inner carton (L x W x H): 14.4 x 10 x 16 cm
- Gross weight: 0.55 kg
- Nett weight: 0.249 kg
- Tare weight: 0.301 kg
- GTIN: 2 48 95229 11748 2

### Packaging dimensions

- Packaging type: Box
- Number of products included: 1
- Type of shelf placement: Hanging
- Packaging dimensions (W x H x D): 9.5 x 17.5 x 4.5 cm
- Gross weight: 0.158 kg
- Nett weight: 0.083 kg
- Tare weight: 0.075 kg
- EAN: 48 95229 11748 8

### Product dimensions

- Product dimensions (W x H x D): 9 x 4 x 5 cm
- Weight: 0.055 kg

### UPC

- UPC: 8 40063 20183 5

TAT3216BK/00

# Highlights

### IPX5 water/sweat resistant



With an IPX5 rating, these true wireless headphones are resistant to sustained wetting from any direction. They won't mind a little sweat, and you don't need to worry about getting caught out in the rain.

### Portable charging case



Take your music anywhere. You get great sound from the 6 mm drivers, and 6 hours play time from a single charge. A fully charged case adds another 18 hours. For a quick boost, pop your headphones in the case for 15 minutes and get an extra hour.

### Mono mode



Taking a lot of calls? You can double your talk time by using one earbud while the other one charges. The mic is automatically assigned to the earbud you're using, and you simply swap over when your current earbud is running low on battery.

### Secure, comfortable in-ear fit

You get real comfort thanks to soft, interchangeable silicone ear-tip covers. The ear-tip covers securely insert into your ear canal, creating a perfect seal that diminishes external noise. The wing tips keep each earbud secure.

### Easy control and pairing

Tap the earbud to pause your playlist, take calls, and wake your phone's voice assistant. The headphones are ready to pair in an instant. Once paired, they reconnect with your phone as soon as you open the charging case.

### Philips Headphones app

Enhance the bass. Tone down the treble. The Philips Headphones app puts you in charge of the music you're listening to. Adjust levels yourself or choose from preset sound styles.



Issue date 2023-02-01

Version: 4.2.4

12 NC: 8670 001 73884  
EAN: 48 95229 11748 8

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)