



Philips
Original radio

Bluetooth®
DAB+, FM
USB port for charging
20W



ORT7500



The original radio

Bring on good times with this Original radio. 50s charm borrowed from Philips' 1955 radio design combine with great sound, giving you powerful bass and crystal clear DAB+ and FM radio, also music wirelessly from smart devices via Bluetooth

Enjoy freedom with Bluetooth® wireless technology

- Playback mobile phone and PC music via Bluetooth technology

High fidelity radio experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- DAB+ and FM compatible for a complete radio experience
- Digital tuning with 30 preset stations for extra convenience
- High quality stereo sound system

Easy to use

- Large backlit LCD display for easy viewing in low light
- Built-in clock display
- Auto time synchronization ensures accurate time without fuss
- USB Charging
- Audio-in for easy portable music playback

Contemporary retro design

- Contemporary reinterpretation of the iconic Philetta design

PHILIPS

Original radio
Bluetooth® DAB+, FM, USB port for charging, 20W

Highlights

Bluetooth wireless technology



Playback mobile phone and PC music via Bluetooth technology

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

DAB+ and FM compatible

DAB+ and FM compatible for a complete radio experience

30-preset digital tuning

Digital radio offers you additional music options to your music collection on your Philips audio system. Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored,

you can quickly access your favorite radio station without having to manually tune the frequencies each time.

USB Charging

USB Charging port enables you to charge your mobile devices such as smart phones, iPhone, iPad

Auto time synchronization



With the automatic time setting function in your clock radio, you do not ever have to set the time. The clock synchronizes with radio signals automatically, even when it is switched off. It updates itself within one minute when there is an immediate need for adjustment, and makes routine synchronizations with radio signals to ensure it keeps accurate time always. From the first time you take the clock radio out of the box, to the time a power outage occurs, you can depend on your Philips product to give you the right time, fuss-free and reliably.

Large backlit LCD display



Backlit LCD display ensures easy viewing and operation in low light conditions, and provides clear information at a glance.

ORT7500/10

Built-in clock display

Built-in clock display

Iconic Philetta design



Inspired by 1955 Original Radio - This original radio carries forward the iconic elements of the legendary 1955 Philips radio, also known as Philetta "254". At the time this compact radio wowed its audiences with simplicity design, big sound and crystal clear reception. Philips radio heritage dates back to 1927. Over the decades many models have become renowned radio icons and collectors' items.

AUDIO-IN (3.5mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device to the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.



DIGITAL RADIO



Specifications

Bluetooth® wireless technology

- Version: BT 2.1
- Profiles: A2DP, AVRCP

Clock

- Type: Digital
- Time format: 12H, 24H

Tuner/Reception/Transmission

- Tuner bands: DAB (Band III), FM
- DAB: smart scan, menu, info display
- DAB frequency range: 174.9 - 239.2 MHz
- FM frequency range: 87.5 - 108 MHz
- No. of preset stations: 30 (DAB), 30 (FM)
- Auto digital tuning

Convenience

- Display Type: LCD

Sound

- Sound system: stereo
- Volume control: rotary (digital)

Loudspeakers

- Built-in speakers: 2

Connectivity

- Bluetooth
- Audio in (3.5mm)
- Antenna: FM antenna (75 ohm)

USB Charging

- Yes
- 5V, 1A

Power

- Power type: AC input
- AC power input: 100-240V, 50/60 Hz

Dimensions

- Product dimensions (WxDxH): 325 x 175 x 167 mm
- Packaging dimensions (WxDxH): 390 x 250 x 247 mm

Accessories

- AC power cord (VDE & UK)
- Aux-in cable
- Quick start guide
- Warranty: Warranty leaflet



Issue date 2014-11-25

Version: 2.0.5

12 NC: 8670 001 04228
EAN: 08 71258 16917 83

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com