



Philips
Noise cancellation
headphones

32mm drivers/closed-back

On-ear
Compact folding

SHL3750NC



More sound, less noise

powerful bass

Be immersed in your music with innovative ActiveShield active noise canceling technology. Pressure-relieving cushions provide long wearing comfort and a compact foldable design is ideal for portability and easy storage.

Art of Noise Cancellation

- ActiveShield™ noise canceling reduces noise by up to 97%

Powerful sound

- 32mm neodymium speaker drivers for rich bass
- Closed-back design blocks out noise for noise isolation

Make life more convenient

- Slim and compact foldable design for easy portability

PHILIPS

Highlights

32mm high definition drivers



Finely tuned 32mm neodymium drivers combined with a closed-back acoustic system design and on-ear sealing provide rich bass.

ActiveShield™



ActiveShield™ active noise canceling technology features two feed-backward microphones used for canceling low frequencies. It detects ambient noise and inverting the sound wave, effectively cancelling it out and converting background noise to silence.

Closed-back design



Tuned 32mm neodymium drivers combined with a closed-back acoustic system design and on-ear sealing provide an excellent and impressive precision sound.

Compact folding



Slim and compact foldable design for easy portability on the go.

Specifications

Packaging dimensions

- Packaging dimensions (W x H x D): 19.5 x 20 x 5 cm
- Packaging dimensions (W x H x D): 7.7 x 7.9 x 2.0 inch
- Nett weight: 0.175 kg
- Nett weight: 0.386 lb
- Gross weight: 0.282 kg
- Gross weight: 0.622 lb
- Tare weight: 0.107 kg
- Tare weight: 0.236 lb
- EAN: 69 25970 70828 9
- Number of products included: 1
- Packaging type: Carton
- Type of shelf placement: Both

Outer Carton

- Outer carton (L x W x H): 20.3 x 16.2 x 21.6 cm
- Outer carton (L x W x H): 8.0 x 6.4 x 8.5 inch
- Nett weight: 0.525 kg
- Nett weight: 1.157 lb
- Gross weight: 0.98 kg
- Gross weight: 2.161 lb
- Tare weight: 0.455 kg
- Tare weight: 1.003 lb
- GTIN: 1 69 25970 70828 6
- Number of consumer packagings: 3

Sound

- Impedance: 16 Ohm
- Magnet type: Neodymium
- Maximum power input: 30 mW
- Sensitivity: 105 dB
- Speaker diameter: 32 mm
- Acoustic system: Closed
- Diaphragm: PET
- Frequency response: 10 - 22,000 Hz

Connectivity

- Cable Connection: single sided
- Finishing of connector: gold-plated
- Cable length: 1.2 m
- Connector: 3.5 mm

Power

- Music play time: 40 hr
- Standby time: 50 hr



Issue date 2020-07-08

Version: 2.0.6

12 NC: 8670 001 32215
EAN: 69 25970 70828 9

© 2020 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com