



Philips  
Network Extender

NTX6400

## Control from any location

NetX, the ideal companion to your iPronto wireless control panel extends the reach of your control beyond boundaries.

### **The total control solution**

- A single point for control for home automation systems
- Radio frequency works through walls and from other rooms

### **Connects to wireless networks**

- Optional IR extension module controls hidden equipment
- Integrated WiFi connectivity for wireless networking

### **Easy to setup**

- Control multiple devices with a single touch
- Intelligent setup wizard means no PC needed for installation

# PHILIPS

# Specifications

## Connectivity

- Encryption / security: WEP 128 bit
- IR emitter connectors: 4
- Network mode: DHCP, Fixed IP
- Wireless LAN: 802.11b

## Accessories

- AC/DC Adaptor: 5 V 3 A
- Dual IR emitter wires: 4
- Quick start guide

## Dimensions

- Master carton quantity: 1
- Product dimension (WxDxH) inch: 6.3" x 1.3" x

3.3"

- Product weight (lb): 0.441
- Temperature range (operation): 41°F to 113°F

## Power

- Mains power: AC 100-240 V 50-60 Hz 500 mA

## Customization

- Editor application on PC: iProntoEdit

## Infrared Capabilities

- Operating distance: 33 ft (10 m)
- Transmitting LEDs: 5
- IR emitter connectors: 4



# Highlights

## Home automation control

Control of not only Audio and Video devices but also other devices in the home such as Lighting, Climate, Curtains, etc.

## Radio frequency

A radio technology that allows you to control components not in direct line-of-sight, such as through walls or other obstacles. There are two types of RF used in remote controls: RF to component, and RF to infrared.

## IR extension module

An infrared extension module allows you to control traditional infrared equipment over a radio frequency network.

## Integrated WiFi

WiFi networking, also known as IEEE 802.11 uses radio frequency signals to communicate in a similar fashion as wired computer networks. It uses TCP/IP networking protocols for the basic communication.

## One-touch convenience

One-touch control allows you to perform multiple commands with one press of a button via a macro. A macro combines a string of pre-programmed commands under one single button. Therefore, it simply takes one button press to execute a series of functions.

## Setup wizard

The setup wizard provides a step by step guide that tailors the device to perfectly match your home entertainment system. By learning what equipment you have, and how it is interconnected, the device creates its own macros that allow full control of your home entertainment system.



Issue date 2014-02-07

Version: 3.0.6

12 NC: 3104 207 14501  
UPC: 0 37849 94013 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)