



Philips  
Bluetooth portable  
speaker

**Bluetooth®**  
10 W Output Power  
10 hours play time

**TAVS500**

## All that jazz

Looks to warm your heart. Sound to move your feet. This large retro-style Bluetooth speaker gives you 10 hours play time, powerful bass, and aux-in to connect to any source. Authentic 1950s detailing adds timeless magic to the mix.

### **Retro style. Modern performance.**

- Vintage wooden cabinet. Period 1950s details
- Brass-toned controls and volume-control knob
- 10 hours play time
- Aux-in. Connect to almost any source

### **Tuned for today**

- Clear, detailed sound. 3" full-range driver
- Bass-reflex port. Full, powerful low tones
- 10 W output power
- Up to 10 m wireless range

### **Easy pairing. Easy listening.**

- Speaker buttons for play/pause, power/source, Bluetooth
- USB charging. Micro USB cable included
- Dimensions: 180x84x140 mm
- Weight: 940 g

# PHILIPS

# Specifications

## Accessories

- Included accessories: Quick install guide, USB cable for PC charging, Warranty Card

## Sound

- Output power (RMS): 10W
- Sound System: Mono

## Compatibility

- other Bluetooth-enabled device
- work with: up to iOS 10.2, Bluetooth 4.2 or below

## Connectivity

- Bluetooth profiles: A2DP, AVRCP, HFP

- Bluetooth range: Line of sight, 10M or 30FT
- Bluetooth version: 5
- Audio in (3.5mm)

## Power

- Battery type: lithium polymer (built-in)
- Operating time on battery: 10 hr

## Dimensions

- Packaging dimensions (WxDxH): 22.5 x 13 x 17.3 cm
- Product weight: 0.94 kg
- Weight incl. Packaging: 1.405 kg
- Product dimensions (WxDxH): 18 x 8.4 x 14 cm

# Highlights

## Authentic vintage

This retro-style Bluetooth speaker looks like it's straight out of the 1950s. The vintage wooden cabinet. The brass-toned volume control knob and speaker grille. Details from back when jazz had the edge and rock and roll was just beginning.

## 10 hours play time

The battery gives you 10 hours play time from a full charge. Charging takes around 4 hours and is easy via the included micro USB cable. A simple press of the Bluetooth button gets this speaker ready to pair with your Bluetooth device.

## Crisp sound. Powerful bass.

From hip-hop to EDM. Just because this speaker looks jazz doesn't mean it only plays jazz. Whatever you're listening to, the 3" full-range driver delivers clear, detailed sound. A bass-reflex port fills in the low tones, giving you rounded, powerful bass response.

## Easy listening

A play/pause button on top of the speaker easily controls your music, while volume up/down is via the retro-style knob. When the speaker is on, press the power button to switch between sources. The wireless range is 10 m: perfect for lazy afternoons in the garden or park.

## All your music. Any source.

The 3.5 mm aux-in socket at the back of the speaker lets you connect to almost any external audio source. Turntable, MP3 player, CD player: as long as you have the right cable, you can play your whole library.



Issue date 2022-05-09

Version: 8.4.2

12 NC: 8670 001 61691  
EAN: 69 51613 94035 8

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)