



Philips
Wireless HiFi Headphone

SBCHC8441



2 headphones included

Wireless

No hassles with cables, just the freedom to move around and enjoy music with your FM wireless stereo FM headphone - plus a second headphone for your friend.

You'll forget you're wearing them!

- 3-way adjustment for a better fit and bass performance
- Lightweight design improves comfort for prolonged use.

The perfect wireless listening experience

- ALC helps prevent audible distortion of input signals
- 32mm speaker driver delivers high performance sound

Always ready to go

- FM Wireless transmission for freedom of movement
- 2 headphones means you can share your music with a partner
- Reduces costs by using rechargeable batteries

PHILIPS

Specifications

Sound

- Acoustic system: closed
- Frequency response: 9 - 21 000 Hz
- Magnet type: Ferrite
- Sensitivity: 100 dB
- Speaker diameter: 32 mm

Tuner/Reception/Transmission

- Pilot tone frequency: 19
- Effective range: 100 m
- Carrier frequency range: 863.0 - 865.0 MHz
- Channel separation: >30 dB
- Modulation: FM
- Number of channel: 2

Convenience

- Automatic power off
- Battery charging indicator
- Operating time: +/- 15 hours
- Low battery indicator
- Double PLL

Power

- Power supply headphone: 2 x 1.5 V NiMH R03/AAA
- Power supply transmitter: AC/DC adapter 12V/200mA

Outer Carton

- EAN: 87 10895 84384 3
- Number of consumer packagings: 6
- Gross weight: 8.761 kg
- Outer carton (L x W x H): 47.4 x 45.4 x 34.5 cm
- Nett weight: 4.878 kg
- Tare weight: 3.883 kg

Packaging dimensions

- EAN: 87 10895 80703 6
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 14.9 x 21.4 x 30.2 cm
- Gross weight: 1.222 kg
- Nett weight: 0.813 kg
- Tare weight: 0.409 kg

Highlights

3-way adjustable ear shells

Enjoy a comfortable fit and experience better bass performance thanks to the three-way adjustable ear shells that fit naturally around your ears.

Lightweight design

The durable, lightweight quality materials of these Philips headphones enhance comfort for extended wearing.

Automatic Level Control (ALC)

This smart electronic circuit ensures that the audio input level is automatically adjusted to the right level, preventing distortion and preserving your listening enjoyment.

32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

FM Wireless transmission

With high frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

2 headphones included

With two headphone sets, you can share the 'personal' listening experience with a friend.

Rechargeable system

The headphone set incorporates facilities for recharging the batteries.

