

Wireless sports headphones

- Washable ear-cup cushions
- Lightweight and rugged
- IP55 dust/water protection

TAA4216BK/00



Stay active. Feel fresh. Rock out.

These tough, lightweight wireless on-ear headphones are built for active lifestyles. Removable and washable ear-cup covers keep you comfortable whether you're hitting the treadmill or the beach. 35 hours play time keeps the music going.

Benefits

Rugged, cool, light.

- Go further. 35 hours play time
- For sports or on the go. Washable ear-cup cushions
- IP55 dust/water protection
- Cooling ear cups

From workout playlist to vital call

- Your tunes stay yours. Closed-back design
- Charge for 15 minutes, get 2 hours extra play time

- Clear sound and powerful bass
- Powerful 40 mm neodymium drivers

From the park to the streets to the beach

- Easy storage. Compact-folding design
- Multi-function button. Built-in mic. Easy pairing
- Compatible with an audio cable (3.5 mm jack)

PHILIPS

Features

35 hours play time



With 35 hours play time from a single charge, these wireless on-ear headphones are with you while you train-and beyond. A full charge takes less than 2 hours. Need an extra boost? 15 minutes charging gives you 2 hours more play time.

Washable ear-cup cushions



The soft, breathable ear-cup cushion sleeves are detachable for easy cleaning and are filled with cooling gel. No matter what you do when you're wearing these headphones, you'll always be able to get them feeling fresh again!

IP55 dust/water protection



An IP55 rating means your headphones are as happy on dusty trails as they are in heavy rain. However hard you sweat-and wherever you go-nothing will stop you!

Specifications

[field not found 'disclaimer_text']

Sound

Impedance	32 Ohm
Speaker diameter	40 mm
Sensitivity	118 dB (1K Hz)
Frequency range	20 - 20,000 Hz
Maximum power input	30 mW
Driver type	Dynamic

Telecommunication

Microphone for call	1 mic
---------------------	-------

Connectivity

Bluetooth version	5.0
Supported codec	SBC
Maximum range	Up to 10 m
Bluetooth profiles	A2DP AVRCP HFP
Type of wireless transmission	Bluetooth
Headphone socket	3.5 mm
Microphone	Built-in microphone
Wireless	Yes

Closed-back design

Perfectly tuned 40 mm neodymium drivers deliver the bass to keep you going. The closed-back construction delivers great passive noise isolation. You get to pump up your tunes without annoying others.

Compact-folding design

The sleek design looks great whether you're going for your personal best or having fun on a weekend break. Inward-folding ear cups make storage easy.

Easy control and pairing

The multi-function button lets you pause your playlist, take calls, control volume, and wake your phone's voice assistant. The headphones are ready to pair the instant you switch on Bluetooth. Once they're paired, they remember the last device they were paired with.

3.5 mm audio port

The 3.5 mm audio port lets you connect these sports headphones directly to compatible phones or music players. Perfect for those times when the battery is running low and you don't have a way to charge your headphones.

Convenience

Water resistance	IP55
Type of controls	Button
Volume control	Yes

Design

Color	Black
Foldable design	In-ward
Wearing style	On-ear
Ear coupling material	Fabric
Ear fitting	On-ear
Earcup type	Closed-back

Power

Music play time	35 hr
Talk time	35 hr
Battery type(Head-phones)	Lithium Polymer (built-in)
Battery capacity(Head-phones)	350 mAh
Charging time	2 hr
Fast charging time	15 mins for 2 hrs
Number of batteries	1 pcs
Battery weight (Total)	6.75 g

Rechargeable Yes

Accessories

Charging cable USB-C cable, 500 mm
Quick Start Guide Yes

Outer Carton

Number of consumer packagings 3
GTIN 1 48 95229 11756 0
Gross weight 1.282 kg
Height 25 cm
Length 22.1 cm
Nett weight 0.714 kg
Tare weight 0.568 kg
Width 18.5 cm

Packaging dimensions

EAN 48 95229 11756 3
Depth 5.5 cm

Gross weight 0.363 kg
Height 23.7 cm
Nett weight 0.238 kg
Number of products included 1
Packaging type Box
Tare weight 0.125 kg
Type of shelf placement Hanging
Width 19.5 cm

Product dimensions

Depth 5 cm
Height 19.9 cm
Weight 0.214 kg
Width 17.2 cm

UPC

UPC 8 40063 20175 0



data subject to change
2023, June 19

Version: 8.2.3
EAN: 4895229117563

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com