Philips Micro Hi-Fi System

MP3/WMA-CD playback

Compact design

# MCM108B

# Compact audio system to match your lifestyle

Great sound in a compact, elegant design! The MCM108B delivers dynamic sound performance and the essential functionalities that will let you enjoy music just the way you like it.

# Enrich your sound experience

- Play MP3/WMA-CD, CD and CD-RW
- · Convenient line-in jack for portable music playback
- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings
- 4W RMS total output power

# Wake up to CD or radio tunes

- Wake up and sleep timer functions
- Stereo tuning with digital readout

Fits any space, any lifestyle

Compact design



# Specifications

#### Sound

- Output Power: 2x2 watts RMS / 200 watts PMPO
- · Sound Enhancement: Dynamic Bass Boost, Digital Sound Control
- Volume Control: Volume Control up/down

# Loudspeakers

• Main Speaker: 3.5" woofer

## **Audio Playback**

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- · Loader Type: Top

# Tuner/Reception/Transmission

• Tuner Bands: FM Stereo, MW


# Connectivity

### · Headphone: 3.5 mm

• Other connections: FM fixed pigtail antenna, MW







#### 150 x 150 x 200 mm • Packaging dimensions (W x H x D): 286 x 200 x 525 mm

• Remote control: 20-key with battery

Included accessories: FM/MW Antenna

• User Manual: English, Traditional Chinese

· Quick start guide: English, Traditional Chinese

• Weight incl. Packaging: 4.31 kg

Antenna

Convenience

Accessories

**Dimensions** 

• Aux in: Line-in, 3.5 mm

• Clock: On main display

· Backlight color: White

Display Type: LCD

• Alarms: CD Alarm, Radio Alarm, Sleep timer



# Highlights

1CM108B/98

## **Dynamic Bass Boost**

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

# **Digital Sound Control**

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Issue date 2012-08-14

© 2012 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 1.0.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 38168 EAN: 87 12581 40467 3

www.philips.com