

You have it, we play it!

Does size matter? Ever heard of less is more? Introducing the best value DVD-player. No complications! Just a simple set that plays practically any disc format, including your digital photos, with absolutely no compromise to picture quality.

Fits everywhere, goes anywhere

- Compact size
- Ultra slim design

Superb video performance

- Progressive Scan (PAL & NTSC) for razor-sharp and flicker-free images
- 4x video upsampling for improved image quality
- 12bit video DAC

Plays practically any disc format

- Movies: DVD, DVD+R/RW, DVD-R/RW, VCD and SVCD
- Music: CD, MP3-CD, CD-R and CD-RW
- Pictures: Picture CD (JPEG)



PHILIPS

Technical specifications

Playback formats

- Video: DVD, DVD+R/RW, DVD-R/-RW, VCD and SVCD
- Audio: CD, CD-R/RW, MP3-CD* (-256 kbps)
- Pictures: Picture-CD (JPEG)

* Plays MP3-CD (supports 32, 56, 64, 96, 128, 256 kbps and variable bit-rate)

DVD functionality

- Multi-angle selection
- Audio selection
- Subtitles selection
- Aspect Ratio Conversion (16:9, 4:3 Letter-Box, 4:3 Pan Scan)
- Disc Menu support
- Parental control
- Repeat track/disc/A-B
- Zoom
- Disc Resume

Picture-CD & MP3-CD functionality

- Playback of pictures automatically
- Picture selection
- Zoom
- Photo-editing capabilities: Rotate, Flip
- Album and track selection

Connections

- Video output:
 - Component video (Y,Pb, Pr)
 - S-Video
 - CVBS (Yellow cinch)
- Audio output:
 - Digital : coaxial (cinch)
 - Analog : line-out (white/red cinch)

Video performance

- Progressive Scan : PAL & NTSC
- Video decoding : MPEG-2/MPEG-1
- Video format : 4:3/16:9
- Video system : PAL/NTSC
- Video DAC : 12bit

Audio performance

- Audio decoding, PCM, Dolby Digital (via digital out)
- Audio DAC : 24 bit, 96 kHz
- Signal to Noise ratio : 95 dB
- Dynamic range : 90 dB
- Crosstalk : 90 dB
- Distortion/noise : 85 dB

Power supply

- Power requirement : 120-230V, 50-60Hz
- Power consumption : approx. 12W
- Standby power : 0.7W

General

- Local and on-screen display
- 33-key remote control
- Smart picture

Product highlights

Progressive Scan (PAL & NTSC)


Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending field with the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A flicker-free high resolution image is created giving you the best viewing.

4x Video Upsampling

Video Upsampling is a technology that decreases distortion to dramatically improve picture quality.

Smart Picture

Smart Picture provides the optimum picture settings for color, brightness, saturation, contrast, sharpness, etc., to enhance your overall viewing experience at all times.



EAN 87 10895 79382 7 (/78)

EAN 87 10895 79385 8 (/AK)

EAN 87 10895 80949 8 (/05)

Dimensions (w x h x d):

360mm x 43mm x 285mm (DVD player)

425mm x 115mm x 340mm (Pack/carton)

Weight:

2.98 kg (Pack/carton)

Bundled equipment:

DVD-Video player, Remote Control, 2x AA battery,

1x two pin adaptor (round to flat) for /78 only, user manual

Date of issue 2003-12-16 **Final**

Specifications are subject to change without notice

Trademarks owned by Royal Philips Electronics

2003 © Royal Philips Electronics - All rights reserved

www.philips.com

