



Philips
docking speaker

for iPod/iPhone
Rechargeable battery



DS7650



Tough enough to travel the world with you

Obsessed with sound

Compact and extremely portable, this docking speaker is no lightweight when it comes to performance. Designed to travel, it delivers sound from your iPod/iPhone that is surprisingly powerful - letting you enjoy great music wherever you go.

Sound that blows you away

- wOOx technology for rich yet precise bass without distortion
- DBB to preserve low tones for deep bass at any volume level
- Shielding technology to block mobile phone interference

Made to go places

- Elegant, slim and compact design to fit into any briefcase

Truly portable and versatile

- Crushproof and shockproof for safe transit
- Built-in rechargeable Li-ion battery for long music playback
- Dock any iPod/iPhone, even in its case
- AUX-in for easy connection to almost any electronic device
- Free DockStudio app for Internet radio and other cool features

PHILIPS

Docking speaker
for iPod/iPhone Rechargeable battery

Highlights

wOOx technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

Dynamic Bass Boost (DBB)



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adapters. What's more, it works even when most protective cases are on - just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.

Crushproof and shockproof

This portable docking speaker is built for worry-free handling. Featuring state-of-the-art engineering, the docking station is innovatively constructed for the ultimate in shock-absorbency and structural rigidity. Built to withstand drops of up to two metres and the pressure of weights of up to 100 kg/220 pounds, the dock's unmatched ruggedness means you can truly bring it everywhere you go, knowing that it will emerge safely from transit.

DockStudio app on App Store



The free app adds an array of exclusive cool features to your docking speaker. You can check the weather, tell the time and even use your favourite images as wallpaper. DockStudio also lets you listen to thousands of Internet radio stations worldwide. More updates on skin styles and new functions on the way.

DS7650/10

Specifications

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPod compatibility

- Compatible with: iPod touch, iPod touch 2nd generation, iPod touch 3rd generation, iPod touch 4th generation

iPod/iPhone App

- App name: DockStudio, Free download from App store
- Compatibility: iPod Touch, iPhone iOS 4.3 or later
- 7000+ Internet radio stations
- 5-day weather forecast
- Playback: Album/track navigation, Playback controls
- Sound settings: DBB, DSC-Flat, Pop, Rock, Jazz, Classic
- Clock: analogue display, digital display
- Alarm: multiple alarms, sleep timer

Connectivity

- Aux in

Sound

- Output power (RMS): 10 W
- Sound System: Stereo

Accessories

- Cables: 3.5 mm AUX-in

Power

- Power supply: 100-240 VAC, 50/60 Hz, Battery
- Battery Type: Built-in battery
- Operating time on battery: 8 hr

Dimensions

- Product dimensions (WxDxH): 305 x 47 x 115 mm
- Packaging dimensions (WxDxH): 151 x 80 x 396 mm
- Weight: 0.8 kg
- Weight incl. Packaging: 1.1 kg



Issue date 2014-03-19

Version: 5.0.3

12 NC: 8670 000 80509
EAN: 87 12581 61659 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com