



Philips
Micro music system

Bluetooth®
CD, MP3-CD, USB, FM
USB port for charging

BTM2310

Relax to great music

Obsessed with sound

Listen to your smartphone tunes, stream your music library over Bluetooth and play MP3-CDs on this compact, all-in-one Philips music system. Charge all your smart devices, from smartphones to tablets with the built-in USB charging port.

Enrich your sound experience

- 15 W maximum output power
- Digital Sound Control
- Bass Reflex Speaker System delivers a powerful, deeper bass

Enjoy your music from multiple sources

- Wireless music streaming via Bluetooth
- Play MP3-CD, CD and CD-R/RW
- Audio-in for portable music playback
- USB Direct for easy MP3 music playback

Easy to use

- Motorised CD loader for convenient access
- Digital tuning with preset stations for extra convenience

PHILIPS

Highlights

Wireless music streaming



Bluetooth is a short range wireless communication technology that is both robust and energy-efficient. The technology allows easy wireless connection to iPod/iPhone/iPad or other Bluetooth devices, such as smartphones, tablets or even laptops. So you can enjoy your favourite music and sound from videos or games wirelessly.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Audio-in



The Audio-in connectivity allows direct playback of Audio-in content from portable media players.

Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set balanced, clear, powerful, warm and bright controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalising technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Specifications

Sound

- Sound enhancement: digital sound control
- Maximum output power (RMS): 15 W

Loudspeakers

- Speaker drivers: 3" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, repeat, shuffle, stop

Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- Antenna: FM fixed pigtail antenna
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug and play)

Connectivity

- USB: USB host
- Audio in (3.5 mm)
- Bluetooth profiles: A2DP

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display type: LED display
- Loader type: tray

Accessories

- Included accessories: AC Power Cord, FM antenna, User Manual
- Remote control: 21-key remote

Dimensions

- Main unit width: 180 mm
- Main unit height: 121 mm
- Main unit depth: 247 mm
- Main speaker dimensions (W x D): 150 x 125 mm
- Main speaker height: 238 mm
- Packaging width: 577 mm
- Packaging height: 312 mm
- Packaging depth: 185 mm
- Gross weight: 4.67 kg
- Net weight: 3.55 kg

Power

- Power supply: 100-240 VAC, 50/60 Hz



Issue date 2022-04-29

Version: 3.0.7

12 NC: 8670 001 11798
EAN: 08 71258 17117 64

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com