



Philips
Portable DVD Player

DVD, VCD, CD, MP3-CD
playback

PET101



Portable DVD player for all

Sit back, relax and watch movies on the Philips PET101. Enjoy your favorite DVD, DivX[®], MPEG4 movies, MP3-CD and CD music, or admire your JPEG photos.

Immerse in ultimate AV entertainment

- Play DVD, DVD+/-R and DVD+/-RW, (S)VCD, DivX[®] & MPEG4 movies
- Plays MP3-CD, CD and CD-RW music
- Share JPEG image files with Picture CD

Easy to use

- As small as portable CD player
- Connect to stereo and TV via standard A/V cables
- Few buttons for simple and easy control

PHILIPS

Highlights

Play DVD, DivX and MPEG4

With DivX® support, you are able to enjoy DivX® encoded videos in the comfort of your living room. The DivX® media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX®

CDs can be played back on selected DVD players, DVD Recorders and Home Theater Systems.

MP3-CD, CD and CD-RW music

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without

radically degrading their audio quality. A single CD can store up to 10 hours of music.

Share picture CD (JPEG)

Multi-format playability allows you to view images on the go and play most disc formats for maximum disc compatibility and viewing pleasure.



Specifications

Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, DVD+R/+RW, CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL
- Compression formats: Divx, MPEG4

Audio Playback

- Compression format: Dolby Digital, MP3
- MP3 bit rates: 32 - 320 kbps
- Playback Media: CD, CD-RW, MP3-CD, CD-R
- File systems supported: ISO-9660, Joliet

Sound

- Signal to noise ratio: >80dB

Connectivity

- DC in: 12V
- AV output: Composite (CVBS) x1

Accessories

- AC/DC Adaptor: DC-IN 12V, 110-240v, 50/60Hz
- Remote control: AY5513 slim remote
- Cables: 1 x AV Cables
- User Manual: 8 languagese

Dimensions

- Master carton dimensions: 205 x 305 x 300 mm
- Master carton quantity: 4
- Master carton weight: 4.29 kg
- Packaging dimensions (W x H x D): 278 x 190 x 68 mm
- Packaging type: D-box
- Product dimensions (W x H x D): 156 x 31 x 150 mm
- Product weight: 0.89 kg



Issue date 2017-04-05

Version: 1.0.5

12 NC: 8670 000 47461
EAN: 87 12581 45060 1

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com