

Philips
DVD player

DivX Ultra

DVP5140



Turn up your experience

With DivX Ultra playback

Be impressed with this Philips DVD player. Step into another home entertainment arena as you immerse yourself in DivX movies and Windows Media Audio in your own living room.



Great audio and video performance

- Progressive Scan component video for optimised image quality
- RGB on Scart single connection for high-quality video
- 12-bit/108 MHz video processing for sharp, natural images
- 192 kHz/24-bit audio DAC enhances analogue sound input

Plays it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD, DivX
- DivX Ultra Certified for enhanced playback of DivX videos
- Music: CD, MP3-CD, CD-R/RW & Windows Media™ Audio
- Picture CD (JPEG) with music (MP3) playback

Fits everywhere, goes anywhere

- Ultra-slim design

PHILIPS

sense and simplicity

Specifications

Picture/Display

- **Aspect ratio:** 4:3, 16:9
- **D/A converter:** 12-bit, 108 MHz
- **Picture enhancement:** Progressive Scan, Video upsampling, Smart Picture

Sound

- **D/A converter:** 24-bit, 192 kHz
- **Frequency response:** 30-20,000 Hz
- **Signal to noise ratio:** 100
- **Distortion and Noise (1 kHz):** 85 dB
- **Crosstalk (1 kHz):** 100 dB
- **Dynamic Range (1 kHz):** 90 dB
- **Sound System:** Dolby Digital

Video Playback

- **Playback Media:** CD, CD-R/CD-RW, Video CD/SVCD, DVD, DVD-R/-RW, DivX, DVD+R/+RW
- **Compression formats:** MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra
- **Video disc playback system:** PAL, NTSC

Audio Playback

- **Playback Media:** CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW
- **Compression format:** MP3, Dolby Digital, PCM, WMA
- **MP3 bit rates:** 32 - 256 kbps

Still Picture Playback

- **Playback Media:** DVD-R/-RW, DVD+R/+RW,

- CD-R/RW, Picture CD, Kodak Picture CD
- **Picture compression format:** JPEG
- **Picture enhancement:** Flip photos, Rotate, Slideshow with MP3 playback, Zoom

Connectivity

- **Rear Connections:** Analogue audio Left/Right out, Composite video (CVBS) output, Scart, Digital coaxial out, ComponentVideo out Progressive

Convenience

- **Child Protection:** Child Lock, Parental Control
- **On-Screen Display languages:** Dutch, English, French, German, Danish, Finnish, Italian, Norwegian, Portuguese, Turkish, Spanish, Swedish, Polish

Power


- **Power supply:** 50 Hz, 230 V
- **Power consumption:** < 10 W
- **Standby power consumption:** < 0.8 W

Accessories

- **Included Accessories:** 2 x AAA Batteries, Quick start guide, Remote Control, World Wide Warranty leaflet, User Manual

Dimensions

- **Set dimensions (W x H x D):** 435 x 37 x 235 mm
- **Packaging dimensions (W x H x D):** 490 x 82 x 320 mm



Product highlights

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, it writes both fields at the same time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

RGB on Scart connectivity

RGB on Scart is a cable connection that provides easy connectivity for high-quality video output.

12-bit/108 MHz video DAC

12-bit Video DAC is a superior Digital-to-Analogue Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother gradation of colours, resulting in a more vibrant and natural picture. The limitations of the standard 10-bit DAC become particularly apparent when it is used with large screens and projectors.

192 kHz/24-bit audio DAC

192 kHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

Multi-format Movies with DivX

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

DivX Ultra Certified

With DivX support, you can enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files such as movies, trailers and music videos on media, e.g. CD-R/RW and DVD recordable discs. DivX Ultra combines DivX playback with great features including integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

Music: Windows Media™ Audio

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

Picture CD with MP3 Playback

Picture CD is a CD-R or CD-RW disc on which you can store your MP3 and digital pictures. When you insert a Picture CD in the DVD player, a screen menu will pop up, showing your JPEGs and/or MP3 files on the disc. Just select the music and picture files you wish to enjoy and press play or OK. You can watch your pictures on TV with your music playing simultaneously.

Ultra-slim design

The attractive enclosure has a very low profile.

