

Philips docking speaker

with Lightning connector for iPod/iPhone 8 W, Battery or AC operated



**AD315** 

# Enjoy music from your iPhone 5

On your desk or anywhere else, the AD315 docking speaker delivers crystal-clear sound that fills your room. Compatible with iPhone 5 and the latest iPods via the Lightning connector. AC or battery option lets you enjoy your music anywhere.

### Crystal clear sound

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Shielding technology to block mobile phone interference

## Enjoy your favourite music

- · Fast charging and play music via Lightning connector
- Audio-in for portable music playback

### **Advanced versatility**

• Battery or AC power option for music enjoyment anywhere



## **Specifications**

#### iPhone compatibility

· Compatible with: iPhone 5

#### iPod compatibility

Compatible with: iPod nano 7th generation, iPod touch 5th generation

#### Sound

- Output power: 8 W RMS
- Sound system: stereo
- Volume control: up/down

#### **Connectivity**

Audio in (3.5 mm)





#### **Dimensions**

- Product dimensions (WxDxH):  $300 \times 133 \times 116 \text{ mm}$
- Packaging dimensions (WxDxH): 387 x 161 x 143 mm
- Product weight: 1.3 kg
- Weight incl. Packaging: 1.65 kg

#### **Power**

- Power supply: 100 240 V AC, 50/60 Hz
- Battery type: AA size (LR6)
- Number of batteries: 4
- Battery life time: 8 hr

## AD315/05

## Highlights

#### **Bass Reflex Speaker System**



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

#### Play and charge via Lightning



Enjoy your favourite music while charging your iPod/iPhone via the new Lightning connector! Just dock it directly on the speaker to play your hand-picked tunes in superb sound. It also charges your device quickly while it's playing, so you don't have to worry about the battery running out.

#### Audio-in



The Audio-in connectivity allows direct playback of Audio-in content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.



Issue date 2014-10-07

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 1.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 07243 EAN: 08 71258 16988 81

www.philips.com