

Philips  
Digital PhotoFrame

17.8 cm (7")

Multimedia 4:3 frame ratio

SPF2107



# "...look, here's you in the bath!"

## Baby PhotoFrame

This PhotoFrame is the perfect combination of quality and fun. Colourful frame accessories are included for personalisation - pink for a girl and blue for a boy. Change the frame to a cute clock by simply switching to Animated Kiddie Clock mode

### Top quality display for amazing viewing experience

- 4:3 aspect ratio for optimal distortion-free display
- imagen Pro for sharp, vibrant and natural skin colours
- Add new glow to old memories with RadiantColor

### Simple intuitive operation and great convenience

- Automatic slideshow from USB or memory card
- Animated Clock displays time in a relaxing way
- Customise your frame with Pink or Blue snap-on frames.

### Environmentally friendly green design

- Eco-friendly Photoframe
- Auto on/off display at pre-set times for power saving



asimpleswitch.com

**PHILIPS**  
sense and simplicity

# Specifications

## Picture/Display

- Viewing angle: @ C/R > 10, 120° (H)/100° (V)
- Lifetime, to 50% brightness: 20,000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600
- Brightness: 250 cd/m<sup>2</sup>
- Contrast ratio (typical): 300:1

## Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

## Storage Media

- USB: USB flash drive
- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo (via adapter), MS Pro Duo (via adapter)
- Built-in memory capacity: 512 MB (for 500 HD photos)

## Convenience

- Card Reader: Built in (2 x)
- Photo format supported: Up to 10 MB JPEG files, Up to 20 Megapixels, JPEG photo
- Video format supported: MotionJPEG, .AVI
- Background Music supported: MP3
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Album management: Create, Delete, Edit, Rename
- Photo edit: Copy, Delete, Rotate, Zoom and crop
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Setup function: Brightness adjustment, Language, Slideshow, Status, Auto on/off, Beep on/off, Set time and date, Photo source, Clock display enable/disable, Event reminder with snooze
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory
- Regulatory approvals: C-Tick, CE, GOST, Switzerland
- Placement: Photo auto orientation, Landscape, Portrait
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Portuguese, Russian, Simplified Chinese
- Photo effects: Black and White, Sepia
- Plug and Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X

- Screen background: Black, White, Grey, Auto-fit
- Other convenience: Kensington lock compatible

## Accessories

- Included accessories: AC-DC Adapter, Quick start guide, USB cable, User manual on CD-ROM
- User Manual: Arabic, Czech, Danish/Norwegian, Dutch, English, Finnish, French, German, Greek, Italian, Malay, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish

## Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

## Power

- Power supply: 100-240 VAC, 50/60 Hz
- DC output Volt: 9 V
- DC output Ampere: 1 A
- Power consumption: (System on) 5.6 W
- Power mode supported: AC powered

## Packaging dimensions

- Packaging dimensions (W x H x D): 22.5 x 19 x 9 cm
- Net weight: 0.7 kg
- Gross weight: 1.05 kg
- Tare weight: 0.35 kg
- EAN: 87 12581 49570 1
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 8.9 x 7.5 x 3.5 inch
- Gross weight: 2.315 lb
- Net weight: 1.543 lb
- Tare weight: 0.772 lb

## Outer Carton

- Outer carton (L x W x H): 23.4 x 19 x 19.8 cm
- Net weight: 1.4 kg
- Gross weight: 2.3 kg
- Tare weight: 0.9 kg
- GTIN: 1 87 12581 49570 8
- Number of consumer packages: 2
- Gross weight: 5.071 lb
- Outer carton (L x W x H): 9.2 x 7.5 x 7.8 inch
- Net weight: 3.086 lb
- Tare weight: 1.984 lb

# Highlights

## imagen Pro for vibrant colours

The unique Philips imagen enhancement technology automatically analyses your photos to correct colour and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more colour accuracy, colour depth and smart contrast. On top of these, imagen Pro offers enhanced skin colour, sharper images and flicker-free photo viewing which is very important for still pictures.

## 4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo is displayed in 4:3 ratio for the best viewing experience.

## Customise with snap-on frames

Two beautifully designed and cheerful frame accessories are included. Pink for girls and blue for boys — sweet dreams guaranteed. Simply snap on.

## Automatic slideshow

Automatic slideshows start from any USB drive or memory card for all those times you don't want to spend time copying photos to your PhotoFrame.

## Baby Animated Clock

Switch to this fun and colourful clock when you don't need to view photos. Instantly, your PhotoFrame becomes a clock. The Animated Kiddie Clock is ideal for children and it is a great tool for teaching them to tell the time.

## RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

## Eco-friendly PhotoFrame

Philips PhotoFrames are designed and produced according to our EcoDesign principles aimed at minimising overall environmental impact through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

## Auto on/off display

A timer turns PhotoFrame on and off at the times you choose, reducing energy consumption for the sake of our environment and saving up to one third of your PhotoFrame energy costs.



Issue date 2011-07-13

Version: 3.3.4

12 NC: 8670 000 55181  
EAN: 87 12581 49570 1

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)