

Philips
Micro Hi-Fi System

MP3/WMA-CD playback
USB Direct

MCM710



Rich sound in a compact design

with USB Direct playback

Specifically designed for those who truly appreciate the ultimate in style and technology, Philips MCM710 exudes finesse and quality. Enjoy MP3/WMA music from your portable player with USB Direct playback.

Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- 100W RMS total output power

Refined in sound and look

- Elegant wood-finished speakers

Start the day your way

- Digital tuning with 20 preset stations for extra convenience
- Wake up and sleep timer functions

PHILIPS

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Loudness

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.



Specifications

Sound

- Sound Enhancement: Loudness, Digital Sound Control 4 modes, Dynamic Bass Boost
- Output Power: 2x50W RMS / 2x100W music power

Loudspeakers

- Main Speaker: 2 way, 4" woofer, Bass Reflex Speaker System, Speaker grilles detachable, Piezo tweeter

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD-RW, CD-R, CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Motorised, Tray
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Tuner/Reception/Transmission

- Auto digital tuning
- Tuner Bands: FM Stereo
- Tuner Enhancements: Auto Store
- RDS: Program Type, Radio Text, RDS Clock Set, Station Name
- Station presets: 20

Connectivity

- Other connections: FM Antenna

- Headphone: 3.5 mm
- USB: USB host
- Audio Connections: Analogue Audio In (L/R)

Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- Display Type: VFD display
- Eco Power Standby: 1 watt
- Indications: DIM mode

Accessories

- Included accessories: FM antenna, World Wide Warranty leaflet
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- Remote control: 40-key with Lithium batteries
- User Manual: 16 languages

Dimensions

- Set dimensions (W x H x D): 248 x 110 x 307 mm
- Main speaker dimensions (W x H x D): 170 x 270 x 220 mm
- Packaging dimensions (W x H x D): 558 x 350 x 314 mm
- Weight incl. Packaging: 11 kg

Power

- Power supply: 220-240V, 50Hz



Issue date 2014-02-06

Version: 1.0.7

12 NC: 8670 000 36685
EAN: 87 12581 39227 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com