



Philips
Portable MP3-CD Player

EXP5463



Super slim and sturdy design

with charging cradle and wearable remote

The super-slim and ultra-sturdy eXp5463 MP3-CD player with unique rubber-metal door will wow your senses. Savor 80 hours of non-stop MP3 and WMA music. Enjoy ultimate convenience with an LCD remote control and bypacked charging cradle.

Your complete MP3-CD experience

- Plays CD, CD-R and CD-RW discs
- Enjoy MP3 and WMA playback

Designed for urban groove

- Compact and convenient charging cradle
- Super slim casing with unique rubber-metal door
- Wearable backlight LCD remote control with ID3 Tag

Non-stop music enjoyment

- Magic ESP™ for skip-free music on the move
- Savour up to 80 hours music playback

PHILIPS
sense and simplicity

Specifications

Sound

- **D/A converter:** 1-bit
- **Frequency response:** 20 - 20 000 Hz
- **Signal to noise ratio:** > 85dB
- **Sound Enhancement:** Digital Dynamic Bass Boost
- **Volume Control:** digital
- **Acoustic Feedback**
- **Output power (RMS):** 2 x 5mW

Audio Playback

- **Playback Media:** MP3-CD, WMA, CD, CD-R, CD-RW
- **Disc Playback Modes:** 50-Track Programmable, Fast Forward/Backward, Hold, Next/Previous Album Search, Next/Previous Track Search, Repeat one/album/all, Resume Playback from stop, Shuffle album/all
- **Magic ESP (MP3-CD):** 100 seconds
- **Electronic Skip Protection(CD):** 45 seconds
- **File systems supported:** ISO-9660, Joliet, UDF
- **ID3-tag support**
- **MP3 bit rates:** 32 - 320 kbps
- **WMA bit rates:** 32 - 192 kbps

Connectivity

- **DC in:** 4.0 mm, 4.5V, centre +
- **Headphone:** 3.5 mm
- **Line-out:** 3,5 mm

Convenience

- **Remote control:** Wearable LCD remote control
- **Display Type:** LCD
- **Backlight**
- **Backlight colour:** Amber
- **Cradle/ docking station**

- **Charging indication**
- **Indications:** album name, album number, artis name, battery status, Cd functions, DBB, ESP, file name, sound titles, time, track

Accessories

- **Remote control:** AY3802(LCD RC)
- **AC/DC Adaptor:** AY3162(400mA)
- **Cradle:** AY4106 charging cradle
- **Headphones:** SBC HE570/77S
- **Batteries:** AY3363(Ni-MH rechargeable)
- **Included Accessories:** User Manual, AA battery door

Dimensions

- **Housing:** Heat Resistant Body
- **Master carton dimensions:** 377 x 248 x 275 mm
- **Master carton weight:** 3.8 kg
- **Master carton quantity:** 3
- **Packaging dimensions (W x H x D):** 235 x 250 x 120 mm
- **Packaging type:** D-box
- **Product dimensions (WxDxH):** 137X137X18mm
- **Product weight:** 0.18 kg

Power

- **Battery playing time (WMA):** 80h(2xAA+2 recharg.batteries)
- **Battery Playing Time MP3-CD:** 80h(2xAA+2 recharg.batteries)
- **Battery Playing Time CD:** 50h(2xAA+2 recharg.batteries)
- **Battery type:** AA, AAA, LR03, LR6, UM3, UM4
- **Rechargeable**

Product highlights

Charging Cradle

Enjoy the ease and convenience of recharging your CD player simply by docking it in this compact and portable charging cradle. It fits on any desktop and can be stationed anywhere. When you connect the AC/DC adaptor to the charging cradle, the LED indicator will turn red to show that your CD player is charging. Once the rechargeable batteries in the player are fully charged, the LED indicator will turn green. Now your player is fully powered-up so you can continue enjoying your music.

Magic ESP™

Magic Electronic Skip Protection™ ensures skip-free music even when your MP3-CD player is knocked or jolted. Devices with the feature have an intelligent electronic buffer that can store different music formats such as MP3, WMA and CDDA. During playback, music is constantly fed into the buffer. When the device is jolted, music is played from the buffer while the laser promptly refocuses to the point where the shock occurred, and recommences playing to refill the buffer. Magic Electronic Skip Protection™ can offer long skip protection depending on the bit rate of the digital audio file.



Issue date 2007-12-07

Version: 6.0

12 NC: 9073 101 01737
EAN: 87 10895 87016 0

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Battery life varies by use and settings.
* Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.
* Based on 64 kbps WMA encoding.