



Philips  
Portable CD Player

EXP7361

## Super slim and ultra lite MP3-CD player

### Digital FM tuner

If you demand nothing but the best, the eXp7361 MP3-CD player with FM Tuner is what you are looking for. Super slim, and ultra light with a sleek aluminum casing and cutting edge features, the eXp7361 is pure indulgence in every sense.

#### **Your complete audio experience**

- Plays MP3 and WMA digital audio
- Digital tuner with 30-station presets
- Play CD, CD-R and CD-RW discs

#### **Designed for elegance**

- Super slim and ultra light
- Sleek aluminum casing for metal feeling and quality look
- Wearable joystick LCD remote control for total control

#### **Non-stop music enjoyment**

- Continuously play MP3-CD for 102-hour without change battery
- 840-second Magic ESP™

#### **Enhanced bass performance**

- Digital Dynamic Bass Boost for optimized bass at any volume
- Stereo headphone with Bass Wave Tech for enhanced bass

# PHILIPS

# Specifications

## Sound

- Acoustic Feedback
- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Output Power: 2 x 5mW RMS
- Signal to noise ratio: > 85dB
- Sound Enhancement: Digital Dynamic Bass Boost
- Volume Control: 32 steps, digital

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA
- Disc Playback Modes: 50-Track Programmable, Fast Forward/Backward, Hold, Next/Previous Album Search, Next/Previous Track Search, Repeat one/album/all, Resume Playback from stop, Shuffle album/all
- Electronic Skip Protection(CD): 180 seconds
- File systems supported: ISO-9660, Joliet, UDF
- ID3-tag support
- Magic ESP (MP3-CD): 420 seconds(up to 3 titles)
- MP3 bit rates: 32 - 320 kbps
- WMA bit rates: 32 - 192 kbps

## Tuner/Reception/Transmission

- Frequency range: 87.5 - 108 MHz
- Station presets: 30
- Tuner Bands: FM Stereo

## Connectivity

- DC in: 4.0 mm, 4.5V, centre +
- Headphone: 3.5 mm
- Line-out: 3,5 mm

## Convenience

- Backlight
- Display Type: LCD
- Indications: album name, album number, artis name, battery status, Cd functions, DBB, ESP, file

- name, sound titles, time, track
- Remote control: Wearable LCD remote control

## Accessories

- AC/DC Adaptor: AY3170(300mA)
- Batteries: AY3365(gum)
- CD-ROM: AY4484(Musicmatch)
- External Battery Pack: AY3380(AA/LR6/UM3)
- Headphones: SBC HE570/77S
- Included accessories: User Manual
- Pouch: AY3268

## Dimensions

- casing material: Aluminium
- Ebox dimensions (W x H x D): 0 x 0 x 0 mm
- Housing: Heat Resistant Body
- Master carton dimensions: 188 x 166 x 240 mm
- Master carton quantity: 3
- Master carton weight: 2.2 kg
- Packaging dimensions (W x H x D): 240 x 56 x 150 mm
- Packaging type: D-box
- Product dimension (WxDxH) inch: 134x130x14.5mm
- Product weight: 0.14 kg

## Power

- Battery Playing Time CD: 65h(2xAA+2 recharg. batteries)
- Battery Playing Time MP3-CD: 102h(2xAA+2 recharg.batteries)
- Battery Playing time (Tuner): 108h(2xAA+2 recharg.batteries)
- Battery Playing time (WMA): 102h(2xAA+2 recharg.batteries)
- Battery type: AA, AAA, LR03, LR6, UM3, UM4
- Kind of Battery: Rechargeable
- Rechargeable

# Highlights

## Plays MP3 & WMA digital audio

Plays MP3 and WMA digital audio

## 30-presets digital tuner

Digital tuner with 30-station presets

## Play CDs, CD-R and CD-RW

Philips is known for making products which are compatible with many discs available in the market. This audio system lets you enjoy music from CD,CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.

## Super slim and ultra light

Super slim and ultra light

## Sleek aluminum casing

Sleek aluminum casing for metal feeling and quality look

## Wearable LCD remote control

Wearable joystick LCD remote control for total control

## Up to 102-hour playback

Continuously play MP3-CD for 102-hour without change battery

## 840-second Magic ESP™

Magic Electronic Skip Protection™ is a convenient feature that ensures skip-free music even when your MP3-CD player is subjected to knocks and jolts while you are jogging or on the move. Devices with Magic Electronic Skip Protection™ have an intelligent electronic buffer that can store different digital music formats such as MP3, WMA and CDDA. The buffer adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

## Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

## Bass enhanced stereo headphone

Stereo headphone with Bass Wave Tech for enhanced bass



Issue date 2014-02-05

Version: 3.0.4

12 NC: 9073 101 00899  
EAN: 87 10895 79129 8

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Battery life varies by use and settings.

\* Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

\* Based on 64 kbps WMA encoding.