



Philips
Outdoor Power Bank

AC/DC output

USB A & USB C charging ports
Power Delivery
Pure Sine Wave

DLP8098CG



Portable Power Bank for camping and more

2000 Watt power storage.

Outdoor Power Bank with AC/DC output for the traveller. Max output 2000W with 1597Wh battery capacity Supports solar panel charging (purchased separately) Includes AC adapter and car charger cable.

Superior Charging Design

- Smart protection against overheat, overvoltage & overcurrent

Top Performance

- 5V/3A fast charging
- USB-C port with Power Delivery support

Portable power

- Works anywhere - great when you're not near a power source
- AC and DC output
- Works with solar panel charger

Confirm operation at a glance

- LCD display for power indication

PHILIPS

Outdoor Power Bank
AC/DC output USB A & USB C charging ports, Power Delivery, Pure Sine Wave

DLP8098CG/11

Specifications

Accessories

- Cables: AC Adapter + Car Charger Cable

Compatibility

- Works with the following: AC socket and USB A & C port

Packaging dimensions

- EAN: 48 95229 12970 2
- Number of products included: 1

Power

- Battery Capacity: 39Ah@51.2V 1997Wh (13Ah*48)
- Battery type: Lithium-Ion
- Output: AC Output, DC5221, XT60 USB-A & USB-C
- Power input: AC Input and Anderson Input

Product dimensions

- Product dimensions (W x H x D): 39.2 x 27.9 x 32.3 cm
- Weight: 24 kg

Design and finishing

- Materials: ABS and Metal

Outer Carton

- Number of consumer packagings: 2
- GTIN: 1 48 95229 12970 9

Inner Carton

- GTIN: 2 48 95229 12970 6
- Number of consumer packagings: 1



Highlights

AC and DC output

The Outdoor Power Bank provides both AC and DC current supply. Safely use electrical appliances with Pure Sine Wave power supply, or charge your mobile phone with the USB (USB A \USB C) charging port.

LCD display for power status

LCD display for power indication

Works with solar panel charger

The Outdoor Power Bank supports solar power panel charging. Keep your devices fully charged; an essential feature when AC power is not readily available.

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

USB-C port with PD

USB-C is the latest charging connector which is now adopted by mobile devices such as cell phones, outdoor cameras and tablets. PD (Power delivery) is the USB standard for power delivery which defines the standard for power delivery of 15W, 27W, 45W and up to 100W.



Issue date 2022-05-29

Version: 1.1.1

12 NC: 8670 001 86479
EAN: 48 95229 12970 2

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com