

Philips Micro Hi-Fi System

Made for iPod MP3/WMA-CD playback

MCM138D

Obsessed with sound

Relax with great music

Dock your iPod player. Listen to your music from one simple control. Great sound and stylish design. Sit back and relax, enjoy your music all day, your way.

Enrich your sound experience

- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 4W RMS total output power

Wake up to CD or radio tunes

- · Wake up and sleep timer functions
- Stereo tuning with digital readout

Fits any space, any lifestyle

- · Compact design
- Play and charge your iPod simultaneously
- One remote control for both system and iPod



Highlights

Play MP3/WMA-CD, CD and CD-RW

Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Play and charge your iPod

Enjoy your favorite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.

Remote control system and iPod

One remote control for both system and iPod















Specifications

Sound

- Output power: 2 x 2 W RMS
- Sound enhancement: Dynamic Bass Boost, digital sound control
- Volume control: up/down

Loudspeakers

- Speaker drivers: 3.5" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- Docking playback modes: fast forward and backward, next and previous track, play and pause

Tuner/Reception/Transmission

- Tuner bands: FM stereo, MW
- · Antenna: MW antenna

Connectivity

- Audio/Video output: Headphone (3.5mm)
- Others: cradle connection

Convenience

- · Alarms: CD alarm, HDD alarm, radio alarm
- · Clock: on main display, sleep timer
- · Loader type: top

- · Display type: LCD display
- · Backlight color: white
- · Charging device: iPod

iPod compatibility

 Compatible with: iPod, iPod mini, iPod nano, iPod with color display, iPod 5th generation

Accessories

- Remote control: 20-key with lithium battery
- User Manual: multi-languages
- Others: cradle and adaptors for iPod, MW loop antenna

Dimensions

- Gross weight: 5.01 kg
- Main speaker dimensions (W x D): 150 x 204 mm
- Main speaker height: 153 mm
- Main unit depth: 244 mm
- Packaging width: 302 mm
- · Main unit height: 153 mm
- Packaging height: 531 mm
- Main unit width: 150 mm
- Packaging depth: 202 mm

Power

- Power supply: 50 Hz
- Power supply: 220 240 V



Issue date 2014-02-06

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 4.0.8

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 30927 EAN: 87 12581 34138 1

www.philips.com