

Philips  
In.Sight wireless HD home  
monitor

## Wi-Fi and HD

Wide angle, Night vision  
For iPhone, iPad  
Powered by Ivideon



M120

## Watch over your home from your iPhone/iPad

### With HD and night vision

Keep an eye on home with the In.Sight wireless HD home monitor via your iPhone/iPad. With HD video and night vision, it lets you clearly see your home in daylight or darkness. It's easy to set up and will alert you when it detects motion/sound.

#### Stay close to loved ones when you're on the move

- Wi-Fi enabled for placement anywhere in your home
- Unlimited live viewing via Wi-Fi/3G/4G LTE
- Extra-wide-angle lens to let you see more
- InSightHD app available on Apple Store
- Night vision mode for viewing in the dark

#### Alerts and notifications for ultimate peace of mind

- Phone receives notification when motion/sound is detected
- Push to talk via iPhone/iPad
- Share monitors with other iPhone/iPad users
- Optional cloud video recording when sound/motion is detected

#### Easy, safe and secure

- Easy setup of monitor via QR code
- Video encrypted for secure connection
- Powered by Ivideon, a leading firm in video cloud solutions



# PHILIPS

# Highlights

## Wi-Fi enabled



The In.Sight wireless monitor is a Wi-Fi enabled monitor. It uses your home wireless network to stream live video and audio with monitors that you can set up anywhere you like.

## Night vision mode



Infrared night vision mode allows you to watch your home even in the dark. When it's dark, infrared light goes on so the monitor can capture clear black-and-white video. Night

vision mode switches on and off automatically, or you can adjust it manually.

## Extra-wide-angle lens



Philips In.Sight wireless HD home monitor M120 boasts a viewing angle of 102 degrees that shows you more of the room at once, letting you see a lot more than other monitors.

## Push to talk

With the In.Sight monitor, not only can you keep an eye on your home, but you can also talk to your loved ones. Simply press "talk" on your iPhone/iPad and communicate at once. What a great way to say hello!

## Motion/sound notifications



It's impossible to predict when something might happen. In.Sight keeps watching with adjustable motion and sound detection. You will be notified automatically when sound or motion is detected.

## Easy set-up via QR code



Setup is simple with the In.Sight+ app. The app will generate a QR code for your home Wi-Fi settings. With the QR code, the monitor will automatically pair with your Wi-Fi network, easily and instantly.



# Specifications

## Lens and Sensor

- Sensor: HD 720p
- Focus mode: Fixed
- View angle: 102 degrees
- Focus range: 0.8 M to infinity
- Ambient light sensor: Yes, day/night mode
- Night mode: Infra-Red

## Video Quality

- HD/VGA/QVGA streaming
- Formats: H.264 video compression
- White Balance: Automatic white balance
- Exposure: Automatic exposure control

## Features

- Wi-Fi: 802.11 b/ g/ n (2.4 GHz)
- Motion detection
- Noise detection
- LED indicator
- Night Vision
- Base: Direction adjustable

## Software

- App name: InSightHD

- Installation: via App
- Automatic App update
- System supported: iOS6 or above
- iPad compatibility: iPad 2 and later
- iPhone compatibility: iPhone 4S and later
- iPod compatibility: iPod Touch 4th gen and later

## Accessories included

- USB power adapter: 1
- USB cable: Yes, 3m
- Wall mount
- Screws/wall anchors: 2
- Quick Start Guide

## Input and Output

- Microphone: Highly sensitive, Mono
- USB: Mini-USB port
- Speaker: Built-in

## Dimensions

- Packaging dimensions (W x H x D):  
158 x 160 x 78 mm
- Product dimensions (W x H x D):  
65 x 114 x 65 mm



Issue date 2014-11-28

Version: 8.2.8

12 NC: 8670 001 02363  
EAN: 08 71258 16852 25

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)