

Philips
Headphones

15-mm drivers/open-back
Earhook

SHS3300WT



Extra bass

for powerful sound

Enjoy the bass beat sound of ear clip headphones designed for comfort, stability and performance.

Always ready to go

- A 1.2 m long cable that is ideal for outdoor use

Made to fit you and your lifestyle

- Ear cushions improve wearing comfort and bass response
- Contoured ear hook increases wearing comfort and stability
- Asymmetric cable keeps the cable out the way

Music to your ears

- 27 mm speaker driver delivers big sound performance
- Bass beat vents allow air movement for better sound
- Neodymium magnets enhance bass performance and sensitivity

PHILIPS

Headphones
15-mm drivers/open-back Earhook

Specifications

Sound

- Acoustic system: open
- Diaphragm: Mylar dome
- Magnet type: Neodymium
- Type: Dynamic
- Voice coil: copper
- Frequency response: 12 - 22,000 Hz
- Speaker diameter: 15 mm
- Sensitivity: 102 dB
- Maximum power input: 100 mW
- Impedance: 32 ohm

Connectivity

- Type of cable: copper
- Cable Connection: two-parallel, asymmetric
- Finishing of connector: Gold-plated
- Cable length: 1.2 m
- Connector: 3.5 mm

Outer Carton

- Length: 35.4 cm
- Number of consumer packages: 24
- Width: 19.2 cm
- Gross weight: 1.74 kg
- Height: 23.2 cm
- GTIN: 1 69 51613 99116 6
- Net weight: 0.42 kg
- Tare weight: 1.32 kg

Convenience

- Wearing Style: Earhook

Inner Carton

- Length: 18.2 cm
- Number of consumer packages: 3
- Width: 8.6 cm
- Height: 11 cm
- Net weight: 0.0525 kg
- Gross weight: 0.1782 kg
- Tare weight: 0.1257 kg
- GTIN: 2 69 51613 99116 3

Packaging dimensions

- Height: 17 cm
- Packaging type: Blister
- Type of shelf placement: Both
- Width: 9.5 cm
- Depth: 2.6 cm
- Number of products included: 1
- EAN: 69 51613 99116 9
- Gross weight: 0.0452 kg
- Net weight: 0.0175 kg
- Tare weight: 0.0277 kg

Design

- Colour: White

Dimensions

- Product dimensions (WxDxH):
3.5 cm*1.8 cm*6.1 cm
- Weight: 0.0175 kg

SHS3300WT/10

Highlights

27 mm speaker driver

Compact for wearing comfort, yet big enough to deliver crisp, powerful sound, the 27 mm speaker driver is the perfect size for non-distorted listening enjoyment.

Bass Beat vents

Bass beat vents allow air movement for better sound with a deep, rich bass.

Comfortable ear cushions

The special shape and luxurious materials used for the ear cushions of these Philips headphones ensure a perfect fit for maximum comfort. They prevent audio leakage and enhance bass performance too. The ear cushions are shaped in such a way that they perfectly align with the area around a person's ear.

Contoured ear hook

The ear hook stays put behind your ear even when you're on the move, keeping the earphone comfortably in place and sounding great. The ear hook is the part that is in contact with the back of your ears and keeps the headphones on your ears

Neodymium magnets

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality.

Asymmetric cabling system

This simple yet highly effective solution to cable tangling works effectively by enabling you to hang the cable behind your neck instead of under your chin.

1.2 m cable

The ideal cable length to give you the freedom to put your audio device where you want.



Issue date 2024-03-12

Version: 3.0.6

EAN: 69 51613 99116 9

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com