



In-ear true wireless headphones

- 6mm drivers/ closed-back
- Comfort fit
- IPX4 splash/sweat resistant
- Up to 24 hours of music

TAT3255PP/00

## Your sounds. Your moves.

Wherever. Whenever. These splash- and sweat-resistant true wireless headphones give you great sound and up to 24 hours play time with their charging case. If you're on a long call, you can use just one earbud while the other one charges.

### Benefits

#### Easy pairing. Voice control.

- Multi-function button. Easily control music and calls
- Easily wake your smartphone's voice assistant
- Smart pairing. Automatically find your Bluetooth device
- Switch from music to phone calls with built-in microphone

#### Feels good. Looks good.

- Secure, comfortable fit
- Rubber ear-tip covers in small, medium, and large
- Soft wing tips for a secure fit and a tighter in-ear seal

### Features

#### IPX4

With an IPX4 rating, these true wireless headphones are resistant to splashing from any direction. They won't mind a little sweat, and you don't need to worry about getting caught out in the rain.

#### Up to 24 hours play time

- IPX4 splash- and sweat-resistant
- Portable USB-C charging case. Get up to 24 hours play time
- Mono mode. Switch the mic between earbuds
- 6 hrs per charge. 15-min charge for 1 hr play time
- 6 mm neodymium drivers. Clear sound, punchy bass

#### Portable USB-C charging case.

Hit the road with multiple charges in your pocket. You get up to 6 hours play time on a single charge, plus 18 extra hours from a fully charged case. A short 15-minute charge in the case gives you 1hr and of play time. A full charge of the case takes 2 hours via USB-C.

# PHILIPS

### Mono mode

Need to take a call when your headphones are running low on power? Get more talk time by using one earbud while the other one charges. The mic is automatically assigned to the earbud you're using, and you can simply swap over when needed.

### Secure, comfortable fit

You get great sound from the 6 mm neodymium drivers and you can rock your tunes in real comfort thanks to the snug, lightweight design. Soft, interchangeable ear-tip covers help you find a comfortable in-ear fit.

## Specifications

[field not found 'disclaimer\_text']

### Sound

Impedance	16 Ohm
Speaker diameter	6 mm
Sensitivity	90 dB (1K Hz)
Frequency range	20 - 20,000 Hz
Maximum power input	5 mW
Magnet type	NdFeB
Diaphragm	PET

### Connectivity

Bluetooth version	5.1
Supported codec	SBC
Maximum range	Up to 10 m
Bluetooth profiles	A2DP AVRCP HFP
Type of wireless transmission	Bluetooth
Wireless	Yes

### Convenience

Mono mode for TWS	Yes
Type of controls	Button
Water resistance	IPX4

### Design

Color	Pink
Ear coupling material	Silicone
Ear fitting	In-ear
In-ear fitting type	Silicone ear tip

### Power

Music play time	6 + 18 hr
Battery capacity(Earbud)	50 mAh
Battery capacity(Case)	500 mAh
Battery type(Earbud)	Lithium Polymer (built-in)
Battery type(Charging case)	Lithium Polymer (built-in)
Talk time	5 hr
Charging time	2 hr
Fast charging time	15 mins for 1 hr
Rechargeable	Yes

### Accessories

Charging cable	USB-C cable
----------------	-------------

### Voice assistant

Wake your phone's voice assistant without touching your phone. Ask smartphone's voice assistant to play music, get directions and check informations, and more.

### Smart Bluetooth pairing.

These earphones are ready to pair the instant you take them out of their charging case. Once they're paired, the earphones remember the last device they were paired with.

Charging case	Yes
Eartips	3 pairs (S/M/L)
Quick Start Guide	Yes

### Product dimensions

Height	4.2 cm
Width	3.6 cm
Depth	6.5 cm
Weight	0.049 kg

### Packaging dimensions

Height	17 cm
Width	9.5 cm
Depth	4 cm
Gross weight	0.139 kg
Nett weight	0.049 kg
Tare weight	0.09 kg
EAN	48 95229 11077 9
Number of products included	1
Packaging type	Box
Type of shelf placement	Hanging

### Outer Carton

Number of consumer packagings	24
Length	37.5 cm
Width	27.5 cm
Height	24.5 cm
Gross weight	4.231 kg
Nett weight	1.176 kg
Tare weight	3.055 kg
GTIN	1 48 95229 11077 6

### Inner Carton

Number of consumer packagings	3
Length	17.8 cm
Width	12.8 cm
Height	10.4 cm
Gross weight	0.507 kg
Nett weight	0.147 kg
Tare weight	0.36 kg
GTIN	2 48 95229 11077 3



data subject to change  
2023, June 20

Version: 5.1.2  
EAN: 4895229110779

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)