

Philips  
Micro Hi-Fi System

MP3/WMA-CD playback

MCM275



## Digital Music with USB Direct

Trendy and progressive, unique innovation and style appeals to you. And so will the vividly chic MCM275 with dynamic sound performance packed in a sleek design with MP3/WMA-CD & USB Direct playback that can also be wall mounted.

### Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- Convenient line-in jack for portable music playback

### Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x5W RMS/2x10W music power/400W PMPO

### Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

### Watch your disc spin

- Front motorized CD door with viewing window
- Wall-mountable option for flexible placement

# PHILIPS

# Highlights

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses

graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



# Specifications

## Sound

- Output power (RMS): 2 x 5 W
- Output Power: 2x10 watts music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

## Loudspeakers

- Main Speaker: 2 way, Bass Reflex Speaker System, Piezo tweeter, 4" woofer

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 40-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Front, Motorised
- ID3-tag support

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store
- RDS: Radio Text, Program Type, Station Name

## Connectivity

- Aux in: Line in
- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna
- USB: USB host

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue
- Eco Power Standby: 0.5 watt

## Accessories

- Included accessories: FM/MW Antenna, Screws for wall mounting x2
- Remote control: 24-key with battery

## Dimensions

- Set dimensions (W x H x D): 194 x 269 x 90 mm
- Main speaker dimensions (W x H x D): 160 x 269 x 90 mm
- Packaging dimensions (W x H x D): 310 x 314 x 238 mm
- Weight incl. Packaging: 5.5 kg



Issue date 2017-04-04

Version: 3.0.8

12 NC: 9073 100 13029  
EAN: 87 10895 92595 2

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Music with Digital Right Management not supported.