



Philips  
USB power bank

**10,000 mAh**  
Qi wireless charging  
QC 3.0 and PD  
Black

**DLP9516CB**



## Wireless charger Power bank

With USB-A & Type-C charging ports.

Big 10000mAh capacity battery. Qi wireless charging with Type-C PD and USB-A quickcharge. This the ideal travel mate to provide power to all your mobile devices.

### Top Performance

- Slim portable design
- Qi wireless technology
- Fast 10W wireless charging
- USB-C port with Power Delivery support
- 3 devices charging

**PHILIPS**

USB power bank  
10,000 mAh Qi wireless charging, QC 3.0 and PD, Black

DLP9516CB/69

# Specifications

## Compatibility

- Works with the following: USB charged devices

## Accessories

- Cables: USB-C Charging Cable

## Power

- Battery Capacity: 10000mAh / 37Wh
- Output: Qi :10W, Type-C 3A, USB-A 3A
- Power input: Type-C Input:5V/2A

## Packaging dimensions

- EAN: 48 95229 12274 1
- Number of products included: 1
- Packaging dimensions (W x H x D):  
9.5 x 19.5 x 3 cm
- Gross weight: 0.28 kg
- Nett weight: 0.23 kg
- Tare weight: 0.05 kg

## Outer Carton

- GTIN: 1 48 95229 12274 8
- Number of consumer packagings: 36
- Gross weight: 11 kg
- Outer carton (L x W x H): 40 x 35 x 22.5 cm
- Nett weight: 8.28 kg
- Tare weight: 2.72 kg

## Inner Carton

- GTIN: 2 48 95229 12274 5
- Number of consumer packagings: 6
- Gross weight: 1.75 kg
- Inner carton (L x W x H): 19 x 10.7 x 20.5 cm
- Nett weight: 1.38 kg
- Tare weight: 0.37 kg

## Product dimensions

- Product dimensions (W x H x D):  
8 x 16 x 1.35 cm

# Highlights

## Fast 10W wireless charging

For 10W charging performance, a Quickcharge charger is required. It identifies the charging standard of your wall charger or power strip to provide faster charging automatically.

## Qi wireless technology

The wireless charging, Qi technology, is widely adopted by smartphones and other mobile devices. Philips wireless chargers are compatible with phones and other devices enabled with Qi wireless technology. Simply put the devices on this pad and you will enjoy the effortless charging experience.

## USB-C port with PD

USB-C is the latest charging connector which is now adopted by mobile devices such as cell phones, outdoor cameras and tablets. PD (Power delivery) is the USB standard for power delivery which defines the standard for power delivery of 15W, 27W, 45W and up to 100W.



Issue date 2022-05-09

Version: 1.1.2

12 NC: 8670 001 77319  
EAN: 48 95229 12274 1

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)