

PHILIPS



True Wireless Headphones

Earbuds with a comfortable fit

Super-small charging case

IPX4 splash/sweat resistant

Up to 18 hours play time



TAT1207WT

Grab and go

Grab, connect and go! These fantastic True wireless headphones come with a super-small charging case that slips into your pocket for reliable, convenient sound wherever you go. IPX4 splash and sweat resistant and up to 18 hours play time!

Small charging case holds 18 hours of play time

- Super-small USB-C charging case
- 6 hours play time. 15 minutes quick charge for an extra hour
- Case offers 12 hours extra play time
- IPX4 splash and sweat resistant

Convenient and easy to use

- Integrated controls. Easy to pair
- Built-in mic
- Easily activate your phone's voice assistant
- Make calls in mono mode using a single earbud

Ergonomic. Comfortable. Clear sound

- Secure, comfortable in-ear fit
- 3 extra pairs of silicone ear tips (large, medium, small)
- 6 mm neodymium drivers for clear, balanced sound
- Ergonomically designed

Specifications

Sound

Frequency range: 20 - 20,000 Hz

Speaker diameter: 6 mm

Impedance: 16 Ohm

Maximum power input: 3 mW

Sensitivity: 97 dB (1k Hz)

Driver type: Dynamic

Connectivity

Bluetooth version: 5.2

Wireless

Bluetooth profiles: A2DP, AVRCP, HFP

Maximum range: Up to 10 m

Supported codec: SBC

Type of wireless transmission: Bluetooth

Outer Carton

Length: 22.2 cm

Number of consumer packagings: 24

Width: 22.2 cm

Gross weight: 3.03 kg

Height: 35.5 cm

GTIN: 1 48 95229 12583 1

Nett weight: 1.392 kg

Tare weight: 1.638 kg

Convenience

Water resistance: IPX4

Mono mode for TWS

Type of controls: Button

Inner Carton

Length: 10.3 cm

Number of consumer packagings: 3

Width: 10.2 cm

Height: 16.5 cm

Nett weight: 0.174 kg

Gross weight: 0.332 kg

Tare weight: 0.158 kg

GTIN: 2 48 95229 12583 8

Power

Rechargeable

Number of batteries: 3 pcs

Music play time: 6 + 12 hour(s)

Talk time: 6 hr

Charging time: 2 hour(s)

Fast charging time: 15 mins for 1 hr

Battery type(Charging case): Lithium Polymer (built-in)

Battery type(Earbud): Lithium Polymer (built-in)

Battery weight (Total): 7.8 g

Battery capacity(Case): 280 mAh

Battery capacity(Earbud): 40 mAh

Packaging dimensions

Height: 17.5 cm

Packaging type: Box

Type of shelf placement: Hanging

Width: 9.5 cm

Depth: 3 cm

Number of products included: 1

EAN: 48 95229 12583 4

Gross weight: 0.094 kg

Nett weight: 0.058 kg

Tare weight: 0.036 kg

Accessories

Quick Start Guide

Eartips: 3 pairs (S/M/L)

Charging case

Charging cable: USB-C cable, 200 mm

Design

Color: White

Ear coupling material: Silicone

Ear fitting: In-ear

In-ear fitting type: Silicone ear tip

Telecommunication

Microphone for call: 1 mic

Dimensions

Charging case dimension(WxDxH): 5.79 x 3.61 x 2.57 cm

Earbud dimension(WxDxH): 2.41 x 2.16 x 2.05 cm

Total weight: 0.034 kg

UPC

UPC: 8 40063 20238 2

Voice assistant

Voice assistant compatible

Voice assistant activation: Manual

Voice assistant support

Highlights

Secure, comfortable in-ear fit

These comfortable earbuds fit securely into your ear canals, creating a perfect seal that diminishes external noise. Hear every beat and word! Enjoy real comfort with three sizes of soft, interchangeable silicone ear-tip covers.

Super-small charging case

This super-small case gives you real power in a tiny package. Fully charged, the headphones give you 6 hours play time and a fully charged case adds 12 hours more. For a quick boost, charge your headphones for 15 minutes and get an extra hour!

IPX4 splash/sweat resistant

An IPX4 rating and powerful 6 mm drivers let you enjoy great sound in any weather! The headphones are splash resistant and won't mind a little rain or sweat so you don't need to worry about getting caught in a shower.

Easy control and pairing

Integrated controls on the earbuds let you pause your music, take calls and wake your phone's voice assistant at the touch of a button. Once paired, the headphones will reconnect with your phone as soon as you take them out of the charging case.

Mono mode for calls

Taking a lot of calls? You can double your talk time by using one earbud while the other one charges. The mic is automatically assigned to the earbud you're using so simply swap over when your current earbud runs low on battery.

