



Philips
Portable CD Player

AX3303

Slim and Jogproof

Looking for a CD player that has great features and looks ultra cool? The AX3303 is just the ticket. The players are slim and ultra modern with a unique animated optical encasing and a variety of exciting colours for a fun music experience.

Design for motion

- Slim Portable CD Player with round and compact footprint
- Unique animated optical casing for fun and happiness

Jogproof

- 45-second ESP™

Enhanced bass performance

- Digital Dynamic Bass Boost for optimised bass at any volume
- Stereo headphone with handy volume control

Enjoy all kinds of discs

- Play CD, CD-R and CD-RW discs

PHILIPS

Specifications

Sound

- Acoustic Feedback
- D/A converter: 1-bit
- Frequency response: 20 - 20,000 Hz
- Output Power: 2 x 5 mW RMS
- Signal to noise ratio: > 85 dB
- Sound Enhancement: Digital Dynamic Bass Boost
- Volume Control: digital

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30-Track Programmable, Fast Forward/Reverse, Hold, Introsan, Repeat Play, Resume Playback from stop, Shuffle Play
- Electronic Skip Protection (CD): 45

Connectivity

- DC in: 4.0 mm, 4.5 V, centre +
- Headphones: 3.5 mm
- Line-out: 3.5 mm

Convenience

- Display Type: LCD
- Indications: battery status, CD functions, DBB, ESP, time, track



Accessories

- AC/DC Adapter: AY3170(300mA)
- Batteries: AY3363(Ni-MH rechargeable)
- Headphones: SBC HE225(with volume control)
- Included accessories: User Manual

Dimensions

- Ebox dimensions (W x H x D): 0 x 0 x 0 mm
- Housing: Heat Resistant Body, Lenticular Sheet
- Master carton dimensions: 168 x 315 x 223 mm
- Master carton quantity: 3
- Master carton weight: 2.5 kg
- Packaging dimensions (W x H x D): 203 x 305 x 58 mm
- Packaging type: Clamshell
- Product dimension (W x D x H) inch: 137.5 x 137.5 x 23.3 mm inch
- Product weight: 0.2 kg

Power

- Battery Playing Time CD: 20
- Battery type: AA, AAA, LR03, LR6, UM3, UM4
- Rechargeable

Highlights

Round, slim and compact

Slim Portable CD Player with round and compact footprint

Animated optical casing

Unique animated optical casing for fun and happiness

45-second ESP™

Electronic Skip Protection is a convenient feature that ensures skip-free music even when your CD player is subjected to knocks and jolts while you're jogging or on the move. Devices with Electronic Skip Protection have an intelligent electronic buffer that adjusts both its contents and its laser spin speeds automatically to guarantee uninterrupted music listening.

Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimised bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

Headphone with volume control

Stereo headphone with handy volume control

Play CDs, CD-Rs and CD-RWs

Philips is known for making products that are compatible with many discs available on the market. This audio system lets you enjoy music from CD, CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.



Issue date 2016-11-17

Version: 2.0.3

12 NC: 9073 101 01259
EAN: 87 10895 81485 0

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com