

Philips  
Clock radio for iPod/  
iPhone with wOOx™  
Technology

DC320



## Wake up to your iPhone/iPod music

wOOx technology for powerful bass

Wake up to your favourite iPhone/iPod music or the radio. PureDigital and wOOx technologies combine to deliver living bass with superior sound clarity. The built-in MP3 link lets you playback music from other portable music players too.

### Rich and clear sound

- wOOx™ loudspeaker Technology for deep and powerful bass
- Pure digital processing technology for best sound clarity
- 12W RMS total output power

### Start the day your way

- Wake up to your iPod/ iPhone music or radio tunes
- Weekday/ weekend alarm setting to complement your lifestyle
- Gentle wake up call with an increasing alarm volume

### Easy to use

- Play and charge your iPod/iPhone simultaneously
- FM digital tuning with presets
- MP3 Link for portable music playback
- All-in-one remote control for your system and iPod/iPhone

**PHILIPS**

# Specifications

## iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS

## iPod compatibility

- Compatible with: iPod touch, iPod touch 2nd Generation, iPod touch 2nd Gen 8/16/32GB, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod classic, iPod 5th Generation, iPod with color display, iPod mini, iPod nano 1st Generation, iPod nano 2nd Generation

## Audio Playback

- Cradle playback mode: Charging iPhone, Charging iPod, Fast forward and backward, Next and Previous track, Play and Pause

## Tuner/Reception/Transmission

- Tuner Bands: FM
- Auto digital tuning
- Station presets: 20
- Antenna: FM Antenna

## Convenience

- Clock/Version: Digital
- Alarms: Dual alarm time, Buzzer Alarm, Radio Alarm, Repeat alarm (snooze)
- User convenience: Sleep Timer
- Backlight
- Backlight color: White
- Display Type: LCD
- Remote Control: Multi-functional

## Sound

- Output power (RMS): 2 x 6W
- Sound System: Stereo
- Volume Control: Volume Control up/down

## Loudspeakers

- Built-in speakers: 5
- Neodymium magnet system
- Loudspeaker Enhancement: wOOx Bass Radiator

## Connectivity

- MP3-Link: Yes, 3.5mm jack

## Power

- Mains power
- Power supply: 100-240VAC, 50/60Hz

## Dimensions

- Master carton dimensions: 221 x 187 x 372 mm
- Master carton quantity: 2
- Master carton weight: 3 kg
- Packaging dimensions (W x H x D): 212 x 172 x 181 mm
- Weight incl. Packaging: 1.4 kg
- Product dimensions (W x H x D): 156 x 187 x 150 mm
- Weight: 0.9 kg

## Accessories

- Included accessories: 3.5mm stereo line in cable, AC-DC Adapter, Quick Use Guide, User Manual, Warranty certificate

# Highlights

## Weekday/ weekend alarm



Designed with modern day lifestyles in mind, this clock radio has a dual alarm feature, allowing you to set different alarm times for weekdays and weekends or even vary the alarm settings for couples. The alarm settings can be tailored for the same alarm times for the entire week from Monday to Sunday. Or you can set the alarm for an early start on weekdays from Monday to Friday, and lazy lie-ins for Saturday and Sundays. Whichever you choose, this convenient features saves you from the hassle of fiddling with different alarm times every single night.

## Pure digital sound



Advanced pure digital sound processing technology offers vastly superior sound performance compared to the conventional analog audio processing technology that is found in docking players that use the analog audio output from an iPod/iPhone. By collecting the iPod's/iPhone's digital audio output and employing digital processing at each stage of the circuit, a much higher Signal-to-Noise ratio is produced. The result is unsurpassed sound clarity that is in perfect balance.

## wOOx™ Technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.



Issue date 2013-05-10

Version: 1.0.1

12 NC: 8670 000 65208  
EAN: 87 12581 55252 7

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)