

Philips docking sound system

• Dock for iPod/iPhone/iPad

DC5070



Enjoy iPod/iPhone/iPad music in superb sound

Obsessed with sound

Bask in big sound from this towering Philips Docking system that features a 2.1 speaker system, a powerful integrated subwoofer and 120 W power output. Atop this elegantly unique speaker is an easily accessible dock for the iPod/iPhone/iPad.

Enjoy your music from multiple sources

- Play and charge your iPod/iPhone/iPad
- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback
- FM digital tuning with presets
- Single remote control for the system and iPod

Enrich your sound experience

- 2.1 system with a built-in subwoofer
- 120 W RMS total output power
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound

Design that blends into your interior

• Unique tower design to fit your lifestyle



Highlights

Play and charge iPod/iPhone/iPad



Enjoy your favourite MP3 music while charging your iPod/iPhone/iPad! The dock lets you connect your portable device directly to the Philips system so you can listen to your favourite music in superb sound. It also charges your iPod/iPhone/iPad while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The system automatically charges your portable device while it is docked.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

FM digital tuning with presets



Digital FM radio offers you additional music options to your music collection on your

Philips audio system. Simply tune into the station that you want to preset, press and hold the preset button to memorise the frequency. With preset radio stations that can be stored, you can quickly access your favourite radio station without having to manually tune the frequencies each time.

120 W RMS



This system has a 120 W RMS total output power. RMS refers to Root Mean Square, which is a typical measurement of audio power, or rather, the electrical power transferred from an audio amplifier to a loudspeaker, which is measured in watts. The amount of electrical power delivered to the loudspeaker and its sensitivity determines the sound power that is generated. The higher the wattage, the better the sound power emitted by the speaker.

USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.













Specifications

iPod compatibility

 Compatible with: iPod classic, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod touch, iPod with colour display, iPod 5th generation, iPod nano 4th generation, iPod nano 5th generation, iPod touch 2nd gen 8/16/32 GB, iPod touch 2nd Generation, iPod touch 3rd generation, iPod touch 4th generation

iPhone compatibility

Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPad compatibility

• Compatible with: iPad, iPad 2

Sound

- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost
- Volume control: up/down
- Output power (RMS): 120 W

Loudspeakers

- No. of built-in speakers: 3
- Speaker drivers: 3" woofer
- Loudspeaker enhancement: bass reflex speaker system
- Subwoofer types: active, integrated subwoofer
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: USB flash drive
- Docking playback modes: fast forward and reverse, next and previous track, play and pause

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- · Antenna: FM antenna
- Station presets: 20
- Tuner enhancement: auto digital tuning

Connectivity

- USB: USB host
- MP3 Link: 3.5 mm stereo line in

Convenience

- Display type: LCD display
- · Alarms: iPod alarm, USB alarm, radio alarm
- · Clock: Digital, sleep timer
- Charging device: iPod, iPad, iPhone

Accessories

- Cables/Connection: power cord
- · Remote control
- Others: User Manual
- Warranty: Warranty Certificate

Dimensions

- Main unit depth: 350. mm
- Main unit height: 978 mm
- Main unit width: 350 mm
- Packaging width: 1130 mm
- · Packaging height: 422 mm
- Packaging depth: 398 mm
- Gross weight: 13 kg
- Net weight: 10.7 kg

Power

• Power type: AC Input

Green

• Eco Power standby: 1 W



Issue date 2013-05-29

Version: 2.1.7

© 2013 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 78438 EAN: 87 12581 60860 6

www.philips.com