



Philips
Universal remote control

6-in-1

SRU7060



Home entertainment control

Operates more than 1200 brands

The superior technology in this stunning universal remote control empowers you to control your complete home entertainment centre from one stylish design unit.

Single control solution for most devices and brands

- 6-in-1 remote for your TV, VCR, STB, DVD, CD and AMP.
- Convenient IR learning from another remote
- Ready for use with Philips equipment

Great convenience

- Eye-catching chrome-plated finish
- The user interface lights up when you pick up the device
- Control multiple devices with a single touch

Easy setup

- Automatically searches for your equipment brand
- Code entry for direct setup of your remote control
- For questions and assistance call our URC service line
- URC support service via dedicated website

PHILIPS
sense and simplicity

Specifications

Convenience

- Universal IR database: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- TV functions: Programme up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu Control, Colour/Brightness control, Teletext keys, Fast text keys, Previous programme, Sleep/timer, 16:9, Guide, info
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- SAT/CBL functions: Digit keys, Menu Control, Guide, info, Favourites, Text functions
- VCR functions: Transport keys (6), Showview, VCR plus, Menu Control
- Backlight
- Backlight colour: Red
- Pre-programmed for Philips
- Simple system setup
- Copy key function
- Installation steps: 2
- Language support: GB/F/D/NL/DK/S/N/FIN/I/E/P
- Number of keys: 39
- Regulatory Approvals: CE Mark
- Splash-proof
- Teletext enhancements: Fast text
- Tilt: Tilt sensor
- Ease of Installation: Autosearch

Accessories

- Battery: Yes, 1.5 V Battery AA LR6

Infrared Capabilities

- Learning IR codes
- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 300
- Carrier frequency range: 28–70kHz
- Transmission angle: 90 degree
- Learning frequency range: 30–60 kHz
- Operating distance: 33 ft (10 m)

Power

- Battery lifetime: 12 months
- Battery type: AA/LR6 Alkaline
- Number of batteries: 2

Outer Box

- Length: 354 mm
- Width: 121 mm
- Height: 177 mm
- EAN/UPC/GTIN: 87 10895 93581 4
- Quantity: 3

Packaging Data

- 12NC: 908210006466
- EAN/UPC/GTIN: 87 10895 93580 7
- Length: 338 mm
- Height: 45 mm
- Width: 155 mm

Highlights

Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

Chrome-plated design

Stylish chrome finish that looks good and complements the latest equipment design.

Automatic backlighting

No more searching for buttons in the dark, because when you pick up the remote control, the keys (or LCD display) automatically light up.

One-touch convenience



One-touch control allows you to perform multiple commands with one press of a button via a macro. A macro combines a string of pre-programmed commands under one single button. Therefore, it simply takes one button press to execute a series of functions.

Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.

Direct code entry

If your remote doesn't automatically find your equipment brand you can always manually key in its digit code from the comprehensive list supplied in the instructions for use.



Issue date 2009-07-17

Version: 2.1.8

12 NC: 9082 100 06466
EAN: 87 10895 93580 7

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com