

Philips
Kitchen Clock Radio
• DVD
• LCD-TV
A L700

Rich Video and Audio Experience

Maximize your entertainment experience with the assertive AJL700! With an awesome mix of DVD playback and LCD-TV, you can totally immerse in music and movies – and never leave your kitchen!

Enjoy your favorite movies and music

- Play DVD, MP3-CD, CD and CD-R/RW
- LCD TV with integrated tuner for terrestrial reception
- PAL/NTSC compatible

Unexpected power

- Dynamic Bass Boost for deep and dramatic sound
- Bass Reflex Speaker System delivers a powerful, deeper bass
- · Motorized CD loader for convenience access

Easy to use

- Digital tuning with preset stations for extra convenience
- Cooking timer for your convenience
- Handy remote control



Specifications

Picture/Display

Aspect ratio: 16:9

- Diagonal screen size: 7
- Display screen type: LCD TFT

Sound

- Loudspeaker types: Bass Reflex Speaker System
- Output power (RMS): 2x2W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 2"
- Volume Control: Volume Control up/down

Video Playback

- Disc Playback Modes: A-B Repeat, Fast Backward, Fast Forward, Introscan, OSD, Pause, Slow Motion, Zoom
- Playback Media: DVD, Picture CD, Video CD

Audio Playback

- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Antenna: FM Antenna
- Auto digital tuning
- Station presets: 20
- Tuner Bands: AM, FM

Connectivity

• AV input: Audio (L/R) x1





• DC in: 12V

- Other connections: FM Antenna, TV in (antenna cable)
- Video input: CVBS Video (RCA) 1x

Convenience

- Alarms: Buzzer Alarm
- Backlight
- Backlight color: Amber
- Clock/Version: Digital
- Display Type: LCD
- DVD functions: System menu control, Disc menu control, Digit keys, Subtitle select, Audio settings
- Height Adjustment: 3-step spacer
- Remote Control: Multi-functional

Accessories

 Included accessories: AC-DC Adapter, AM/FM Antenna, Batteries for remote control, Quick install guide, Remote Control, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 486 x 330 x 143 mm
- Product dimensions (W x H x D): 370 x 270 x 75 mm
- Weight: 2.6 kg
- Weight incl. Packaging: 4.1 kg

Power

- Adaptor type: multi-voltage (AC: 100 240 V, 50 -
- 60 Hz) • Mains power



AJL700/37

Highlights

Plays DVD/CD/MP3

Play DVD, MP3-CD, CD and CD-R/RW

LCD TV with integrated tuner

This set has a built in tuner to receive terrestrial signals (PAL/SECAM/NTSC) as well as the sound in your local area format.

PAL/NTSC compatible PAL/NTSC compatible

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Bass Reflex Speaker System Bass Reflex Speaker System delivers a deep bass

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Motorized CD loader

A motorized sliding front door adds even more panache to the already sleek design of this system. The stylish yet functional door housing the disc slides up and down vertically in a smooth motion at the touch of a button whenever you feel like changing your music selection. Just sit back and enjoy the dynamic sound performance while watching the disc play through the transparent window.

Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

Cooking timer

Cooking timer for your convenience

Handy remote control Handy remote control



Issue date 2013-05-10

© 2013 Koninklijke Philips Electronics N.V. All Rights reserved.

Electronics N.V. or their respective owners.

Version: 4.0.5

All Rights reserved. Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips

12 NC: 9073 101 01885 www.philips.com