



Linea V design cordless phone

- 1.8" display/ white backlight
- Handset speakerphone

M3501B/90

The finest line to connect

Design takes centrestage with the precision-engineered Philips LINEA V, with edgy form harmonising with an iconic silhouette. Elegant architecture supports smart functions and comfort, making the LINEA V a must-have masterpiece.

Benefits

Exquisite design with high quality execution

- Calibrated, seamlessly integrated keys for precise dialing
- Slender design and compact footprint for space efficiency
- Charge handset either way around

Ultimate calling experience

- High contrast 4.6cm (1.8") 2-line reverse display
- Save up to 50 favorite contacts in your phonebook
- Handset speakerphone allows you to talk handsfree

- HQ-Sound: high quality acoustic engineering for superb sound
- Stay connected during power cuts via micro-USB power bank
- Privacy settings: call block & call barring
- Enjoy 10 hours of talk time on a single charge

Eco-conscious product

- Zero power emission when ECO+ mode is activated

PHILIPS

Features

4.6cm (1.8") reverse display



High contrast, white-on-black reverse LCD display ensures easy reading and also blends well with the overall sleek design language.

50-name phone book

Save up to 50 favorite contacts in your phonebook.

Calibrated keypad



The calibrated keypad allows you to clearly feel every keystroke whenever you are dialing a number or entering a phonebook contact. Detailed study of keypad materials and structures, as well as extensive user tests result in the right balance between the key pressing force and the key response to ensure precise dialing.

Compact footprint



Slender design and compact footprint for space efficiency

ECO+ mode



Philips phones are energy efficient and designed to be respectful to the environment. When ECO mode is activated the emitted radiation is reduced by up to 60%, and up to 95% when the phone is charging. With ECO+ mode activation the radiation drops to zero.

Specifications

[field not found 'disclaimer_text']

Convenience

Menu structure in the handset	List Menu
Speakerphone - talk handsfree	Yes
Signal strength indicator	3-bar indicator
Battery level indicator	3-bar battery icon

Handset speakerphone



Handsfree mode uses a built-in loud speaker to amplify the voice of the caller, allowing you to speak and listen during a call without holding the phone to your ear. This is especially useful if you want to share the call with others or simply multitask.

Hassle-free charging

HQ-Sound



HQ-Sound: high quality acoustic engineering for superb sound reproduction. We build upon decades of experience and breakthrough innovations in developing Hi-Fi audio products and high-end headphones to deliver excellent voice clarity on our DECT phones. When it comes to improving sound quality, our acoustics engineers and architects have thought of everything - high quality components, digital signal processing, precise acoustic design, advanced testing and fine-tuning. The result is sound that is crisp, clear and authentic. Sound so good and natural, it is almost like being there in person.

Micro-USB connector

The integrated micro-USB connector socket on the base unit ensures that the phone can stay powered via a pre-charged power bank, allowing you to make calls even if the power cuts out. The power bank charging feature supports most power bank products which are able to provide a minimum output current below 85mA without automatic shutdown. Power bank sold separately.

Privacy settings

Value your privacy and quiet at home? Black List restricts specific numbers or those starting with certain digits, protecting you from receiving unwanted calls. You can choose to block up to 4 sets of numbers. Each set can consist of 1 to 24 digits. If the number of an incoming call starts with any of these number sets or are the exact numbers that you chose to blocked, your phone will not ring. With Call Barring, you can avoid the surprise of expensive phone bills by blocking calls to specific numbers starting with certain digits (for example, pay per call numbers).

Up to 10 hours talk time

Enjoy 10 hours of talk time on a single charge

Intercom - multiple handsets	Yes
Date / Time display	Yes
Battery charge indication	Yes
Signal strength indication	Yes
Programmable hot keys	Key 1 and 2

Call Management	Call Waiting* Caller ID* Microphone mute Missed Calls Received Calls Dialed calls Yes Yes Yes 1 Up to 4 Soft Amber Yes Yes 1.8m 1.8m Open field <300m; in door <50m Alarm Clock Paging key Restrict the phone from ringing on specific incoming numbers Restrict the phone from making specific outgoing calls For events status Yes 20 Yes hr	Redial List Capacity Call log entries Phonebook store in the base 10 entries 20 entries Yes
Keypad lock	Yes	
Key tone on/off	Yes	
Auto hang up	Yes	
Multi base capability	1	
Multi handset capability	Up to 4	
Backlit keypad	Soft Amber	
Up to 180 hrs standby time	Yes	
Charge time: 8 hours	Yes	
Line cord length	1.8m	
Power cord length	1.8m	
Range	Open field <300m; in door <50m	
Alarms	Alarm Clock	
Base Station keys	Paging key	
Block callers/ Black-list*	Restrict the phone from ringing on specific incoming numbers	
Call barring	Restrict the phone from making specific outgoing calls	
Event notifications	For events status	
Illuminated keypad	Yes	
Number of keys	20	
Up to 10 hrs talk time	Yes hr	
Sound		
Ringtones on handset	10 polyphonic	
HQ-Sound	Yes	
Volume control on handset	Yes	
Picture/Display		
Display size	4.6cm / 1.8"	
Display type	1-line dot matrix + 1-line numeric + hard icons	
Backlight: Yes	Yes	
Backlight color	White	
Memory Capacity		
Phonebook	50 names and numbers	
Power		
Battery capacity	300 mAh	
Battery type	2xAAA NiMH Rechargeable	
Mains power	AC 100-240V ~50/60Hz	
Power Consumption	< 0.7 W	
Security		
Transmission encryption : Yes	Yes	
Network Features		
Compatible	GAP	
SAR Value		
Philips handsets	<0.1 W/kg	
Eco Design		
Eco+	Yes	
Packaging dimensions		
Packaging type	Carton	
Number of products included	1	
Type of shelf placement	Laying	
Height	22.5 cm	
Width	12.1 cm	
Depth	10.1 cm	
Gross weight	0.569 kg	
Nett weight	0.414 kg	
Tare weight	0.155 kg	
EAN	48 95185 63061 8	
USB Charging		
Yes	Yes	

* *This feature requires additional subscription of Caller ID service. Please check with your local network operator for details.



data subject to change
2018, February 25

Version: 2.2.3
EAN: 4895185630618

© 2018 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com