



Philips
HD Media player

1080p HDMI
Built-in Wi-Fi
USB 2.0



HMP7000

Home Media Player

Effortlessly explore a vast universe of multimedia content with the Philips HD media player. Enjoy superb quality videos, music and photos from the Internet or your PC library directly on your TV—no file conversions required.

See more

- Play video in multiple formats
- DivX Plus HD Certified for high-definition DivX playback
- View photos in various formats

Hear more

- Listen to music from different media files
- Dolby Digital DTS2.0 for the ultimate movie experience

Engage more

- Built-in Wi-Fi to enjoy your connected media wirelessly
- With SimplyShare, enjoy photos, music and films on your TV
- DLNA PC Media Link to browse PC and home network content
- USB 2.0 connector and SD memory card slot
- Playback media content from hard disk

PHILIPS

Highlights

DivX Plus HD Certified



DivX Plus HD on your Blu-ray player and/or DVD player offers the latest in DivX technology to let you enjoy HD videos and movies from the Internet directly on your Philips HDTV or PC. DivX Plus HD supports the playback of DivX Plus content (H.264 HD video with high-quality AAC audio in an MKV file container) while also supporting previous versions of DivX video up to 1080p. DivX Plus HD for true HD digital video.

Video in multiple formats

Play and enjoy a comprehensive range of video formats—from high definition formats like MPEG 1/2/4 (MPEG 4 Part 2), H.264, VC-1, H.263, VP6 (640 x 480), DivX Plus HD, DivX 3/4/5/6, Xvid, RMVB 8/9/10, RM, WMV (V9), AVI, TS, M2TS, TP, TRP, ISO, VOB, DAT, MP4, MPEG, MPG, MOV(MPEG 4, H.264), ASF, FLV (640 x 480), MKV, M4V—without the hassle of converting files. Just press Play to start watching any videos or movies in superb

cinematic quality, delivered in vivid surrounding sound.

Media content from hard disk

Relax and enjoy your media content from your hard disk without worrying about file format compatibility. Simply playback your content knowing that your Philips player supports most popular HDD formats like FAT32, FAT etc.

Photo in various formats



View and enjoy your photos in a wide range of formats, including JPEG, JPG, M-JPEG, PNG, TIF, TIFF, GIF, BMP and HD JPEG — directly on your wide-screen TV! Turn your living room into a photo gallery and share wonderful memories with your friends and family.

Music in different media files

Listen to your favourite music—whatever the audio format—and enjoy it in crystal clear sound. The Philips player allows easy access to a wide range of audio formats from Dolby

Digital, AAC, RA, OGG, MKA, MP3, WAV, APE, FLAC, DTS, LPCM, PCM, WMA (V9), IMP/MS ADPCM and WMA Pro.

Dolby Digital DTS2.0

Dolby Digital DTS2.0 for the ultimate movie experience

DLNA PC Media Link

The DLNA PC Media Link provides easy access to videos, photos and music content on your PC or home network. By connecting your media player to your home network, you will be able to access content from all DLNA certified devices seamlessly. Browse your PC collection of multimedia from your player at a push of a button.

SimplyShare TV



Share photos, music and films through SimplyShare from your smart phone, tablet or computer and enjoy them on the big screen.



Specifications

Picture/Display

- D/A converter: 12-bit, 108 MHz
- Picture enhancement: Video upsampling, Smart Picture, High Def (720p, 1080i, 1080p), Video upscaling

Sound

- D/A converter: 24-bit, 192 kHz
- Frequency response: 30-20,000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1 kHz): 65 dB
- Crosstalk (1 kHz): 70 dB
- Dynamic Range (1 kHz): 80 dB
- Sound System: Dolby Digital, DTS 2.0 + Digital out

Video Playback

- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Plus™ HD, H.264, MKV, VC-1, WMV, XviD
- Video disc playback system: PAL, NTSC

Audio Playback

- Compression format: PCM, MP3, Dolby Digital, DTS, WMA
- MP3 bit rates: 32 - 320 kbps
- Playback Media: SD Card, USB flash drive

Still Picture Playback

- Picture Compression Format: JPEG, BMP, GIF, PNG, TIFF
- Picture Enhancement: Flip photos, Rotate, Zoom, Slideshow with MP3 playback

Connectivity

- Front/Side connections: USB, SD/SDHC Card
- Rear Connections: CVBS and analogue audio L/R output, Digital optical out, HDMI output, eSATA
- Network connections: 802.11 b/g/n, RJ45

Convenience

- On-Screen Display languages: English, Polish, Russian, Czech, Danish, Finnish, French, German, Greek, Hungarian, Italian, Portuguese, Romanian, Slovak, Spanish, Swedish, Turkish, Ukraine
- EasyLink (HDMI-CEC): One touch play, One touch standby
- Firmware upgradeable: Firmware upgradeable via USB

Power

- Power supply: 230 V, 50 Hz

- Power consumption: < 10 W
- Standby power consumption: < 1 W

Accessories

- Included accessories: Audio/Video cable, World Wide Warranty leaflet, Remote Control, 2 x AAA Batteries, User Manual, Power cord

Dimensions

- Set dimensions (W x H x D): 91 x 54 x 160 mm
- Packaging dimensions (W x H x D): 250 x 163 x 82 mm

Multimedia Applications

- Multimedia connections: USB memory class device
- Playback Formats: DivX, JPEG Still pictures, MP3, AVI (DivX, DIV5, DX50, DXMF), DivX 3.11, DivX 5, DivX Ultra, H.264, MPEG1, MPEG2, MPEG-4 (DivX-4 DivX-5 DivX-6), RealMedia Audio, RealMedia Video, WMA, WMV9/VC1, XviD

Digital Photo Playback

- Picture Compression Format: BMP, GIF, JPEG, PNG, TIFF
- Picture Enhancement: Zoom
- Playback Media: SD card, USB flash drive

Outer Carton

- Gross weight: 2.9 kg
- GTIN: 1 87 12581 62598 3
- Outer carton (L x W x H): 27.8 x 26.4 x 20.6 cm
- Net weight: 1.89 kg
- Number of consumer packages: 3
- Tare weight: 1.01 kg

Packaging dimensions

- Packaging dimensions (W x H x D): 26.6 x 18.2 x 8.2 cm
- EAN: 87 12581 62598 6
- Gross weight: 0.86 kg
- Net weight: 0.63 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 0.23 kg
- Type of shelf placement: Laying

Product dimensions

- Product dimensions (W x H x D): 17.8 x 9.1 x 5.75 cm
- Weight: 0.35 kg



Issue date 2017-04-04

Version: 3.2.8

12 NC: 8670 000 84803
EAN: 87 12581 62598 6

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com