

Philips Xperion 3000
Flood Mini

500 lm Boost / 200 lm Eco

300 lm Spotlight
Battery life: 3h (Eco: 8h)
180° pivoting handle

LUMX30FLMINX1/10



Quality light to get the job done

Compact LED projector light

Compact and versatile, the Philips Xperion 3000 Flood Mini rechargeable LED projector light provides the bright white light you need for everyday use. Enjoy up to eight hours of continuous use before charging the battery.

Bright, comfortable work light

- Light up your whole work area

Sturdy lamp for daily use

- Shock resistance proven in drop tests
- Water resistant against splashes

Versatile for hands-free use

- Rotating handle for hands-free use

Versatile and easy to use

- Magnetic mounting accessory for hands-free lighting

Handy and easy to operate

- Rechargeable battery lasts up to 8 hours
- Indicator shows how long the battery will last

PHILIPS

Flood Mini

500 lm Boost / 200 lm Eco 300 lm Spotlight, Battery life: 3h (Eco: 8h), 180° pivoting handle

Specifications

Marketing specifications

- Product highlight: Compact LED projector light
- Expected benefits: Dual lights: flood + spotlight

Product description

- Headband: N/A
- Impact protection rating (IK): IK08
- Ingress protection rating (IP): IP65
- Magnet: Magnetic handle
- Materials & finishing: Nylon+ rubber
- Operating Temperature: 0°C to 40°C
- Orientable light: 180° pivoting handle
- Pointing light
- Range: Xperion 3000
- Resistant to: grease, oil, workshop solvents
- Technology: LED
- UV leak detector: No
- Hook: 180° rotatable

Light characteristics

- Color temperature: 6000 K
- Light output (pointer): 300 lumens
- LED lifetime: 30000 hours
- Beam angle: 110°
- Light output: 500 lumens
- Light output (eco): 200 lumens
- Beam angle (pointer): 30°

Electrical characteristics

- Voltage: 3.7 V
- Battery capacity: 2500 mAh

- Battery run time (boost): Up to 8 hours
- Battery run time: Up to 3 hours
- Battery type: Li-ion battery
- Plug type: Plug not included
- Charging cable type: USB-C cable
- Battery charging time: Up to 3.5 hours
- Power Source: Li-ion battery
- Wattage: 5W +3W Spot

Ordering information

- Order entry: X30FLMIX1
- Ordering code: 72811731

Packaging Data

- EAN1: 6974260728117
- EAN3: 6974260728124

Packed product information

- Length: 10.8 cm
- Width: 5.1 cm
- Height: 15 cm
- Pack Quantity / MOQ: 1
- Weight with batteries: 200 g
- Cable length: 100 cm USB-C cable

Outerpack information

- Length: 20.8 cm
- Width: 24 cm
- Height: 17.6 cm
- Gross weight per piece: 2890 g

LUMX30FLMINX1/20

Highlights

Bright, comfortable work light

Whether you need to light up a work site, temporarily replace a wall lamp, or illuminate outdoor activities, the Philips Xperion 3000 Flood Mini is perfect for lighting up large dark areas. Delivering 500 lumens (5W), its homogeneous bright light gives off an extra-wide beam. If you need less light and more battery life, you can switch to the 200-lumen (5W) Eco mode.

Shock resistant

We've made our Philips Xperion 3000 Flood Mini tough enough for use both indoors and outside. Built to last, this lamp has been subjected to 1.5-meter drop tests and can easily survive occasional drops during use.

Water resistant

Whether you use our Philips Xperion 3000 Flood Mini indoors or outdoors, the lamp is designed to survive in tough conditions. Resistant to water, it will continue to work when splashed, such as during light rain.

Versatile rotating handle

Sometimes you need hands-free lighting so you can focus on your task. The 180 rotating handle on the back of our Philips Xperion 3000 Flood Mini allows you to position the projector as needed. You can also use the handle as a hook to hang the light or as a support to stand it up. This versatility enables you to direct the light just where you need it.

Magnetic mounting accessory

The Philips Xperion 3000 Flood Mini also comes with a magnetic mounting accessory. Attach it to the handle to mount your projector onto any metal surface. Perfect for use in a garage or other work environments.

Up to 8 hours of battery life

Once fully charged, your Philips Xperion 3000 Flood Mini delivers bright white light (500 lumens / 5 W) for up to three hours in Boost mode. If you need longer battery life, switch to Eco mode (200 lumens) and enjoy up to 8 hours of continuous light.

Battery-life indicator

No more worries about your light dying just when you need it most. On the back of the Philips Xperion 3000 Flood Mini is a battery-life indicator which tells you exactly how long you've got before needing to recharge the battery.



Issue date 2023-11-30

Version: 1.1.1

EAN: 69 74260 72811 7

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com