

Philips
True Wireless
Headphones

Small buds. Great value

Natural sound. Dynamic bass
Pocket-sized charging case
Clear calls

TAT1209BK



Get your music on

The best things in life are simple. Grab your headphones, take your tunes, and head out! With great sound, dynamic bass, and a pocket-sized charging case, these super-small and comfy true wireless earbuds are ready for your day-and night.

True wireless earbuds. Great value, great sound.

- Small and comfy earbuds that love a big bassline
- 10mm drivers and dynamic bass boost function
- Clear calls. They'll hear what you're saying

Take your tunes. Make your calls.

- Solid Bluetooth connection
- Pocket-sized charging case
- IPX4 splash and sweat resistant

Simply all you need

- Up to 18 hours play time with the case
- Comfy fit and handy on-ear touch controls
- Interchangeable silicon ear tips
- Warm, natural sound. Philips sound signature

PHILIPS

True Wireless Headphones

Small buds. Great value Natural sound. Dynamic bass, Pocket-sized charging case, Clear calls

Specifications

Sound

- Impedance: 16 Ohm
- Speaker diameter: 10 mm
- Sensitivity: 97 dB (-10 dbfs 1K Hz)
- Frequency range: 20 - 20,000 Hz
- Maximum power input: 10 mW
- Driver type: Dynamic

Telecommunication

- Microphone for call: 1 mic

Connectivity

- Bluetooth version: 5.3
- Supported codec: SBC
- Maximum range: Up to 10 m
- Bluetooth profiles: A2DP, AVRCP, HFP
- Type of wireless transmission: Bluetooth
- Wireless

Convenience

- Water resistance: IPX4
- Mono mode for TWS
- Type of controls: Touch

Design

- Color: Black
- Ear coupling material: Silicone
- Ear fitting: In-ear
- In-ear fitting type: Silicone ear tip

Power

- Music play time: 6 + 12 hr
- Battery type(Earbud): Lithium Polymer (built-in)
- Battery capacity(Earbud): 40 mAh
- Battery type(Charging case): Lithium Polymer (built-in)
- Battery capacity(Case): 300 mAh
- Charging time: 2 hr
- Fast charging time: 15 mins for 1 hr
- Number of batteries: 3 pcs
- Battery weight (Total): 7.5 g
- Rechargeable

Voice assistant

- Voice assistant support
- Voice assistant compatible
- Voice assistant activation: Manual

Accessories

- Eartips: 3 pairs (S/M/L)
- Charging case
- Charging cable: USB-C cable, 200 mm
- Quick Start Guide

Dimensions

- Earbud dimension(WxDxH): 2.23 x 1.79 x 2.19 cm
- Charging case dimension(WxDxH): 5.80 x 3.59 x 2.52 cm
- Total weight: 0.03 kg

Packaging dimensions

- Packaging type: Carton
- Number of products included: 1
- Type of shelf placement: Hanging
- Packaging dimensions (W x H x D): 9 x 9.3 x 3.2 cm
- Gross weight: 0.069 kg
- Nett weight: 0.05 kg
- Tare weight: 0.019 kg
- EAN: 48 95229 13995 4

Outer Carton

- Number of consumer packagings: 24
- Outer carton (L x W x H): 24.2 x 21.8 x 19.8 cm
- Gross weight: 2.355 kg
- Nett weight: 1.2 kg
- Tare weight: 1.155 kg
- GTIN: 1 48 95229 13995 1

Inner Carton

- Number of consumer packagings: 3
- Inner carton (L x W x H): 11.2 x 10 x 8.5 cm
- Gross weight: 0.258 kg
- Nett weight: 0.15 kg
- Tare weight: 0.108 kg
- GTIN: 2 48 95229 13995 8

TAT1209BK/97

Highlights

Small earbuds, great sound

These true wireless earbuds might be small, but you won't need to turn up the volume to get the best sound. Tap the left earbud to activate dynamic bass and you can enjoy the full power of your favourite basslines, even when listening quietly.

Clear calls

Your voice will come through clearly when you're on a call. A dedicated mic picks up the sound of your voice while a noise-reduction algorithm quietsens some of the background noise from the world around you.

Solid Bluetooth connection

Advanced Bluetooth connectivity gives you a more stable connection for seamless streaming. Enjoy that playlist or listen uninterrupted to your favorite podcast without annoying dips in the sound.

Pocket-sized charging case

The slimline charging case slips easily into a pocket, so you can keep your earbuds protected and charging while you're not using them. Mono mode means you can use either earbud while the other one charges.

IPX4 splash/sweat resistant

Never mind the weather, an IPX4 rating means these earbuds are splash resistant so they don't mind a little rain! Wearing them during a quick workout or on a particularly hot day? They won't mind a little sweat either.

18 hours play time with case

You get 6 hours play time from a full charge, and an extra 12 hours from the case. Pop the earbuds back in the case and they'll recharge fully in 2 hours. If you need a quick boost, just 15 minutes gives you an extra hour. The case can be charged via USB-C.

Comfy fit and touch controls

The ear tips rest gently but securely in your ear canal and interchangeable silicone ear-tip covers let you find your perfect fit. Touch controls on the earbuds keep things simple. Activate the dynamic bass-boost function, control playback or pick up a call--and more.

Philips sound signature

Music to podcasts, love what you hear! These true wireless earbuds feature large 10 mm drivers, tuned to the Philips sound signature. Whatever you're into, you'll enjoy a warm, natural sound with deep bass.



Issue date 2023-12-02

Version: 1.0.1

12 NC: 8670 001 91907
EAN: 48 95229 13995 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com