

Philips  
Surge protector

Home office

3 outlets

SPP4031A



## Hide Cable Clutter

Home Electronics surge protector features advanced technology to keep your equipment safe from electrical surges/spikes. Power Blocker circuitry automatically shuts down power to your system to protect against subsequent surges.

### Pure Protection

- 1000 Joules
- Protected Phone/DSL connections
- \$100,000 connected equipment warranty\*
- Power Blocker

### Built-in convenience

- 3 outlets with protection

### Simplicity

- Worry free protection indicators

**PHILIPS**

sense and simplicity

# Specifications

## Packaging dimensions

- Packaging dimensions (W x H x D): 12.2 x 25.4 x 8.4 cm
- Packaging dimensions (W x H x D): 4.8 x 10 x 3.3 inch
- Nett weight: 0.100 kg
- Nett weight: 0.22 lb
- Gross weight: 0.213 kg
- Gross weight: 0.47 lb
- Tare weight: 0.113 kg
- Tare weight: 0.249 lb
- UPC: 6 09585 18098 7
- Number of products included: 1
- Packaging type: Box

## Outer Carton

- Outer carton (L x W x H): 27.9 x 24.9 x 14.2 cm
- Outer carton (L x W x H): 11 x 9.8 x 5.6 inch
- Nett weight: 0.300 kg
- Nett weight: 0.661 lb
- Gross weight: 1.600 kg
- Gross weight: 3.527 lb
- Tare weight: 1.300 kg
- Tare weight: 2.866 lb
- GTIN: 1 06 09585 18098 4
- Number of consumer packagings: 3

# Highlights

## \$100,000 equipment warranty

Protects your connected equipment for the life of the product.

## Power Blocker

Automatically shuts down power to the connected devices.

## 1000 Joules

Prevent thousands of dollars of damage to your electronic devices.

## Protected phone/DSL connection

Sidactors are used for protecting the phone lines. These connectors accommodate an RJ11 cord, routing the telephone line through the surge protector to guard against spikes and surges.

## Protection indicators

LED lights let you know if your surge protector is functioning properly.

## 3 outlets with protection

Protects against surges/spikes through the AC lines by suppressing surge energy. The excess energy is clamped by the MOV when the unit is subjected to a surge event.



Issue date 2013-01-22

Version: 1.1.5

12 NC: 8670 000 58579  
UPC: 6 09585 18098 7

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)