



#### USB power bank

- 10,000 mAh
- Qi wireless charging
- QC 3.0 and PD
- Black

DLP9516CB/69

## Wireless charger Power bank

With USB-A & Type-C charging ports.

Big 10000mAh capacity battery. Qi wireless charging with Type-C PD and USB-A quickcharge. This the ideal travel mate to provide power to all your mobile devices.

### Benefits

#### Top Performance

- 3 devices charging
- Fast 10W wireless charging
- Qi wireless technology

- USB-C port with Power Delivery support
- Slim portable design

### Features

#### Fast 10W wireless charging

For 10W charging performance, a Quickcharge charger is required. It identifies the charging standard of your wall charger or power strip to provide faster charging automatically.

#### Qi wireless technology

The wireless charging, Qi technology, is widely adopted by smartphones and other mobile devices. Philips wireless chargers are compatible with phones

and other devices enabled with Qi wireless technology. Simply put the devices on this pad and you will enjoy the effortless charging experience.

#### USB-C port with PD

USB-C is the latest charging connector which is now adopted by mobile devices such as cell phones, outdoor cameras and tablets. PD (Power delivery) is the USB standard for power delivery which defines the standard for power delivery of 15W, 27W, 45W and up to 100W.

# PHILIPS

## Specifications

[field not found 'disclaimer\_text']

### Compatibility

Works with the following USB charged devices

### Accessories

Cables USB-C Charging Cable

### Power

Battery Capacity Output 10000mAh / 37Wh  
Qi :10W, Type-C 3A, USB-A 3A [Qi power:10W/7.5W/5W Type-C output:5V/3A,9V/2A,12V/1.5A USB1 5V/2.4A USB2 5V/3A,9V/2A,12V/1.5A]  
Power input Type-C Input:5V/2A [Type-C Input: 5V/2A,9V/2A,12V/1.5A]

### Packaging dimensions

EAN 48 95229 12274 1  
Number of products included 1  
Depth 3 cm  
Gross weight 0.28 kg  
Height 19.5 cm  
Nett weight 0.23 kg  
Tare weight 0.05 kg  
Width 9.5 cm

### Outer Carton

GTIN 1 48 95229 12274 8  
Number of consumer packagings 36  
Gross weight 11 kg  
Height 22.5 cm  
Length 40 cm  
Nett weight 8.28 kg  
Tare weight 2.72 kg  
Width 35 cm

### Inner Carton

GTIN 2 48 95229 12274 5  
Number of consumer packagings 6  
Gross weight 1.75 kg  
Height 20.5 cm  
Length 19 cm  
Nett weight 1.38 kg  
Tare weight 0.37 kg  
Width 10.7 cm

### Product dimensions

Depth 1.35 cm  
Height 16 cm  
Width 8 cm



data subject to change  
2023, June 19

Version: 1.1.2  
EAN: 4895229122741

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)